Fluid Mechanics for **Chemical Engineers**

Second Edition, with Microfluidics and CFD

Prentice Hall International Series in the Physical and Chemical **Engineering Sciences**



FREE SAMPLE CHAPTER

SHARE WITH OTHERS











Fluid Mechanics for Chemical Engineers

Second Edition with Microfluidics and CFD

Prentice Hall International Series in the Physical and Chemical Engineering Sciences



Visit informit.com/ph/physandchem

for a complete list of available publications.

■he Prentice Hall International Series in the Physical and Chemical Engineering Sciences had its auspicious beginning in 1956 under the direction of Neal R. Amundsen. The series comprises the most widely adopted college textbooks and supplements for chemical engineering education. Books in this series are written by the foremost educators and researchers in the field of chemical engineering.



★Addison-Weslev

FLUID MECHANICS FOR CHEMICAL ENGINEERS

Second Edition

with Microfluidics and CFD

JAMES O. WILKES

Department of Chemical Engineering The University of Michigan, Ann Arbor, MI

with contributions by

STACY G. BIRMINGHAM: Non-Newtonian Flow
Mechanical Engineering Department
Grove City College, PA

BRIAN J. KIRBY: Microfluidics
Sibley School of Mechanical and Aerospace Engineering
Cornell University, Ithaca, NY

COMSOL (FEMLAB): Multiphysics Modeling COMSOL, Inc., Burlington, MA

CHI-YANG CHENG: Computational Fluid Dynamics and FlowLab Fluent, Inc., Lebanon, NH



Prentice Hall Professional Technical Reference

Upper Saddle River, NJ • Boston • Indianapolis • San Francisco New York • Toronto • Montreal • London • Munich • Paris • Madrid Capetown • Sydney • Tokyo • Singapore • Mexico City Many of the designations used by manufacturers and sellers to distinguish their products are claimed as trademarks. Where those designations appear in this book, and the publisher was aware of a trademark claim, the designations have been printed with initial capital letters or in all capitals.

The author and publisher have taken care in the preparation of this book, but make no expressed or implied warranty of any kind and assume no responsibility for errors or omissions. No liability is assumed for incidental or consequential damages in connection with or arising out of the use of the information or programs contained herein.

The publisher offers excellent discounts on this book when ordered in quantity for bulk purchases or special sales, which may include electronic versions and/or custom covers and content particular to your business, training goals, marketing focus, and branding interests.

For more information, please contact:

U.S. Corporate and Government Sales (800) 382–3419 corpsales@pearsontechgroup.com

For sales outside the U.S., please contact:

International Sales international@pearsoned.com

Visit us on the Web: www.phptr.com

Library of Congress Cataloging-in-Publication Data Wilkes, James O.

Fluid mechanics for chemical engineers, 2nd ed., with microfluidics and CFD/James O. Wilkes.

p. cm.

Includes bibliographical references and index.

ISBN 0-13-148212-2 (alk. paper)

1. Chemical processes. 2. Fluid dynamics. I. Title.

TP155.7.W55 2006

660'.29-dc22

2005017816

Copyright © 2006 Pearson Education, Inc.

All rights reserved. Printed in the United States of America. This publication is protected by copyright, and permission must be obtained from the publisher prior to any prohibited reproduction, storage in a retrieval system, or transmission in any form or by any means, electronic, mechanical, photocopying, recording, or likewise. For information regarding permissions, write to:

Pearson Education, Inc.

Rights and Contracts Department

One Lake Street

Upper Saddle River, NJ 07458


ISBN 0-13-148212-2

Text printed in the United States on recycled paper at Courier Westford in Westford, Massachusetts 8th Printing October 2012

Dedicated to the memory of

Terence Robert Corelli Fox

Shell Professor of Chemical Engineering University of Cambridge, 1946–1959



CONTENTS

PREFAC	JE	XV
	PART I—MACROSCOPIC FLUID MECHANICS	
СНАРТ	ER 1—INTRODUCTION TO FLUID MECHANICS	
1.1	Fluid Mechanics in Chemical Engineering	3
1.2	General Concepts of a Fluid	3
1.3	Stresses, Pressure, Velocity, and the Basic Laws	5
1.4	Physical Properties—Density, Viscosity, and Surface Tension	10
1.5	Units and Systems of Units	21
	Example 1.1—Units Conversion	24
	Example 1.2—Mass of Air in a Room	25
1.6	Hydrostatics	26
	Example 1.3—Pressure in an Oil Storage Tank	29
	Example 1.4—Multiple Fluid Hydrostatics	30
	Example 1.5—Pressure Variations in a Gas	31
	Example 1.6—Hydrostatic Force on a Curved Surface	35
	Example 1.7—Application of Archimedes' Law	37
1.7	Pressure Change Caused by Rotation	39
	Example 1.8—Overflow from a Spinning Container	40
	Problems for Chapter 1	42
СНАРТ	ER 2—MASS, ENERGY, AND MOMENTUM BALANCES	
2.1	General Conservation Laws	55
2.2	Mass Balances	57
	Example 2.1—Mass Balance for Tank Evacuation	58
2.3	Energy Balances	61
	Example 2.2—Pumping n -Pentane	65
2.4	Bernoulli's Equation	67
2.5	Applications of Bernoulli's Equation	70
	Example 2.3—Tank Filling	76
2.6	Momentum Balances	78
	Example 2.4—Impinging Jet of Water	83
	Example 2.5—Velocity of Wave on Water	84
	Example 2.6—Flow Measurement by a Rotameter	89

• • •	a
VIII	Contents

	2.7	Pressure, Velocity, and Flow Rate Measurement	92
		Problems for Chapter 2	96
CF	HAPTE	CR 3—FLUID FRICTION IN PIPES	
	3.1	Introduction	120
	3.2	Laminar Flow	123
		Example 3.1—Polymer Flow in a Pipeline	128
	3.3	Models for Shear Stress	129
	3.4	Piping and Pumping Problems	133
		Example 3.2—Unloading Oil from a Tanker	
		Specified Flow Rate and Diameter	142
		Example 3.3—Unloading Oil from a Tanker	
		Specified Diameter and Pressure Drop	144
		Example 3.4—Unloading Oil from a Tanker	
		Specified Flow Rate and Pressure Drop	147
		Example 3.5—Unloading Oil from a Tanker	
		Miscellaneous Additional Calculations	147
	3.5	Flow in Noncircular Ducts	150
		Example 3.6—Flow in an Irrigation Ditch	152
	3.6	Compressible Gas Flow in Pipelines	156
	3.7	Compressible Flow in Nozzles	159
	3.8	Complex Piping Systems	163
		Example 3.7—Solution of a Piping/Pumping Problem Problems for Chapter 3	165 168
CF	HAPTE	CR 4—FLOW IN CHEMICAL ENGINEERING EQUIPMENT	
	4.1	Introduction	185
	4.2	Pumps and Compressors	188
		Example 4.1—Pumps in Series and Parallel	193
	4.3	Drag Force on Solid Particles in Fluids	194
		Example 4.2—Manufacture of Lead Shot	202
	4.4	Flow Through Packed Beds	204
		Example 4.3—Pressure Drop in a Packed-Bed Reactor	208
	4.5	Filtration	210
	4.6	Fluidization	215
	4.7	Dynamics of a Bubble-Cap Distillation Column	216
	4.8	Cyclone Separators	219
	4.9	Sedimentation	222
	4.10	Dimensional Analysis	224
		Example 4.4—Thickness of the Laminar Sublayer	229
		Problems for Chapter 4	230

Contents

318

PART II—MICROSCOPIC FLUID MECHANICS

5.1 Introduction to Vector Analysis 249 5.2 Vector Operations 250 Example 5.1—The Gradient of a Scalar 253 Example 5.2—The Divergence of a Vector 257 Example 5.3—An Alternative to the Differential 257 Example 5.4—The Curl of a Vector 262 Example 5.5—The Laplacian of a Scalar 263 5.4 The Convective Derivative 266 5.5 Differential Mass Balance 267 Example 5.6—Physical Interpretation of the Net Rate of Mass Outflow 269 Example 5.7—Alternative Derivation of the Continuity 269 Example 5.7—Alternative Derivation of the Continuity 270 5.6 Differential Momentum Balances 271 5.7 Newtonian Stress Components in Cartesian Coordinates 280 Example 5.8—Constant-Viscosity Momentum Balances in Terms of Velocity Gradients 280 Example 5.9—Vector Form of Variable-Viscosity 280 Momentum Balance 284 Problems for Chapter 5 285 CHAPTER 6—SOLUTION OF VISCOUS-FLOW PROBLEMS 6.1 Introduction 292 6.2 Solution of the Equations of Motion in Rectan	СНАРТІ	ER 5—DIFFERENTIAL EQUATIONS OF FLUID MECHANI	[CS
Example 5.1—The Gradient of a Scalar 253	5.1	Introduction to Vector Analysis	249
Example 5.1—The Gradient of a Scalar 253 Example 5.2—The Divergence of a Vector 257 Example 5.3—An Alternative to the Differential Element 257 Example 5.4—The Curl of a Vector 262 Example 5.5—The Laplacian of a Scalar 263 Example 5.5—The Laplacian of a Scalar 263 5.3 Other Coordinate Systems 263 5.4 The Convective Derivative 266 5.5 Differential Mass Balance 267 Example 5.6—Physical Interpretation of the Net Rate of Mass Outflow 269 Example 5.7—Alternative Derivation of the Continuity Equation 270 5.6 Differential Momentum Balances 274 5.7 Newtonian Stress Components in Cartesian Coordinates 274 Example 5.8—Constant-Viscosity Momentum Balances in Terms of Velocity Gradients 280 Example 5.9—Vector Form of Variable-Viscosity Momentum Balance 284 Problems for Chapter 5 285 CHAPTER 6—SOLUTION OF VISCOUS-FLOW PROBLEMS 6.1 Introduction 292 6.2 Solution of the Equations of Motion in Rectangular Coordinates 294 Example 6.1—Flow Between Parallel Plates 294 6.3 Alternative Solution Using a Shell Balance 294 Example 6.2—Shell Balance for Flow Between Parallel Plates 301 Example 6.3—Film Flow on a Moving Substrate 303 Example 6.4—Transient Viscous Diffusion of Momentum (COMSOL) 307 6.4 Poiseuille and Couette Flows in Polymer Processing 205 205 Example 6.5—The Single-Screw Extruder 313 Example 6.6—Flow Patterns in a Screw Extruder 314 Example 6.6—Flow Patterns in a Screw Extruder 315 Example 6.7—Flow Patterns in a Screw Extruder 315 Examp	5.2	· · · · · · · · · · · · · · · · · · ·	250
Example 5.2—The Divergence of a Vector Example 5.3—An Alternative to the Differential Element 257		-	253
Example 5.3—An Alternative to the Differential Element 257		•	257
Element Example 5.4—The Curl of a Vector 262 Example 5.5—The Laplacian of a Scalar 262 5.3 Other Coordinate Systems 263 5.4 The Convective Derivative 266 5.5 Differential Mass Balance 267 Example 5.6—Physical Interpretation of the Net Rate of Mass Outflow 269 Example 5.7—Alternative Derivation of the Continuity Equation 270 5.6 Differential Momentum Balances 271 5.7 Newtonian Stress Components in Cartesian Coordinates 274 Example 5.8—Constant-Viscosity Momentum Balances in Terms of Velocity Gradients 280 Example 5.9—Vector Form of Variable-Viscosity Momentum Balance 284 Problems for Chapter 5 285 CHAPTER 6—SOLUTION OF VISCOUS-FLOW PROBLEMS 292 6.1 Introduction 292 6.2 Solution of the Equations of Motion in Rectangular 294 Coordinates 294 Example 6.1—Flow Between Parallel Plates 294 6.3 Alternative Solution Using a Shell Balance 294 Example 6.2—Shell Balance for Flow Between Parallel Plates 294 Example 6.3—Film Flow on a Moving Substrate 294 Example 6.4—Transient Viscous Diffusion of 301 Momentum (COMSOL) 307 6.4 Poiseuille and Couette Flows in Polymer Processing 312 Example 6.5—The Single-Screw Extruder 313 Example 6.6—Flow Patterns in a Screw Extruder 313 Example 6.7—Flow Patterns in a Screw Extruder 313 Example 6.7—Flow Patte			
Example 5.5—The Laplacian of a Scalar 262		•	257
5.3 Other Coordinate Systems 263 5.4 The Convective Derivative 266 5.5 Differential Mass Balance 267 Example 5.6—Physical Interpretation of the Net Rate of Mass Outflow 269 Example 5.7—Alternative Derivation of the Continuity Equation 270 5.6 Differential Momentum Balances 271 5.7 Newtonian Stress Components in Cartesian Coordinates Example 5.8—Constant-Viscosity Momentum Balances in Terms of Velocity Gradients 280 Example 5.9—Vector Form of Variable-Viscosity Momentum Balance 284 Problems for Chapter 5 285 CHAPTER 6—SOLUTION OF VISCOUS-FLOW PROBLEMS 6.1 Introduction 292 6.2 Solution of the Equations of Motion in Rectangular Coordinates Example 6.1—Flow Between Parallel Plates 294 6.3 Alternative Solution Using a Shell Balance Example 6.3—Shell Balance for Flow Between Parallel Plates 301 Example 6.3—Film Flow on a Moving Substrate Example 6.4—Transient Viscous Diffusion of Momentum (COMSOL) 307 6.4 Poiseuille and Couette Flows in Polymer Processing Example 6.5—The Single-Screw Extruder 313 Example 6.6—Flow Patterns in a Screw Extruder 313 <td></td> <td>Example 5.4—The Curl of a Vector</td> <td>262</td>		Example 5.4—The Curl of a Vector	262
5.3 Other Coordinate Systems 263 5.4 The Convective Derivative 266 5.5 Differential Mass Balance 267 Example 5.6—Physical Interpretation of the Net Rate of Mass Outflow 269 Example 5.7—Alternative Derivation of the Continuity Equation 270 5.6 Differential Momentum Balances 271 5.7 Newtonian Stress Components in Cartesian Coordinates Example 5.8—Constant-Viscosity Momentum Balances in Terms of Velocity Gradients 280 Example 5.9—Vector Form of Variable-Viscosity Momentum Balance 284 Problems for Chapter 5 285 CHAPTER 6—SOLUTION OF VISCOUS-FLOW PROBLEMS 6.1 Introduction 292 6.2 Solution of the Equations of Motion in Rectangular Coordinates Example 6.1—Flow Between Parallel Plates 294 6.3 Alternative Solution Using a Shell Balance Example 6.3—Shell Balance for Flow Between Parallel Plates 301 Example 6.3—Film Flow on a Moving Substrate Example 6.4—Transient Viscous Diffusion of Momentum (COMSOL) 307 6.4 Poiseuille and Couette Flows in Polymer Processing Example 6.5—The Single-Screw Extruder 313 Example 6.6—Flow Patterns in a Screw Extruder 313 <td></td> <td>Example 5.5—The Laplacian of a Scalar</td> <td>262</td>		Example 5.5—The Laplacian of a Scalar	262
Example 5.6—Physical Interpretation of the Net Rate of Mass Outflow Example 5.7—Alternative Derivation of the Continuity Equation 270 5.6 Differential Momentum Balances Example 5.8—Constant-Viscosity Momentum Balances in Terms of Velocity Gradients Example 5.9—Vector Form of Variable-Viscosity Momentum Balance 280 Problems for Chapter 5 CHAPTER 6—SOLUTION OF VISCOUS-FLOW PROBLEMS 6.1 Introduction 6.2 Solution of the Equations of Motion in Rectangular Coordinates Example 6.1—Flow Between Parallel Plates 6.3 Alternative Solution Using a Shell Balance Example 6.2—Shell Balance for Flow Between Parallel Plates Example 6.3—Film Flow on a Moving Substrate Example 6.4—Transient Viscous Diffusion of Momentum (COMSOL) 307 6.4 Poiseuille and Couette Flows in Polymer Processing Example 6.6—Flow Patterns in a Screw Extruder	5.3		263
Example 5.6—Physical Interpretation of the Net Rate of Mass Outflow Example 5.7—Alternative Derivation of the Continuity Equation 270 5.6 Differential Momentum Balances 271 5.7 Newtonian Stress Components in Cartesian Coordinates Example 5.8—Constant-Viscosity Momentum Balances in Terms of Velocity Gradients Example 5.9—Vector Form of Variable-Viscosity Momentum Balance 284 Problems for Chapter 5 CHAPTER 6—SOLUTION OF VISCOUS-FLOW PROBLEMS 6.1 Introduction 6.2 Solution of the Equations of Motion in Rectangular Coordinates Example 6.1—Flow Between Parallel Plates 294 Example 6.3—Alternative Solution Using a Shell Balance Example 6.3—Film Flow on a Moving Substrate Example 6.4—Transient Viscous Diffusion of Momentum (COMSOL) 307 6.4 Poiseuille and Couette Flows in Polymer Processing Example 6.5—The Single-Screw Extruder Example 6.6—Flow Patterns in a Screw Extruder	5.4	The Convective Derivative	266
of Mass Outflow Example 5.7—Alternative Derivation of the Continuity Equation 270 5.6 Differential Momentum Balances 271 5.7 Newtonian Stress Components in Cartesian Coordinates Example 5.8—Constant-Viscosity Momentum Balances in Terms of Velocity Gradients Example 5.9—Vector Form of Variable-Viscosity Momentum Balance Example 5.9—Vector Form of Variable-Viscosity Momentum Balance 284 Problems for Chapter 5 CHAPTER 6—SOLUTION OF VISCOUS-FLOW PROBLEMS 6.1 Introduction 292 6.2 Solution of the Equations of Motion in Rectangular Coordinates Example 6.1—Flow Between Parallel Plates 294 6.3 Alternative Solution Using a Shell Balance Example 6.2—Shell Balance for Flow Between Parallel Plates Example 6.3—Film Flow on a Moving Substrate Example 6.4—Transient Viscous Diffusion of Momentum (COMSOL) 6.4 Poiseuille and Couette Flows in Polymer Processing Example 6.5—The Single-Screw Extruder Example 6.6—Flow Patterns in a Screw Extruder	5.5	Differential Mass Balance	267
		Example 5.6—Physical Interpretation of the Net Rate	
Equation 270 5.6 Differential Momentum Balances 271 5.7 Newtonian Stress Components in Cartesian Coordinates Example 5.8—Constant-Viscosity Momentum Balances in Terms of Velocity Gradients 280 Example 5.9—Vector Form of Variable-Viscosity Momentum Balance 284 Problems for Chapter 5 285 CHAPTER 6—SOLUTION OF VISCOUS-FLOW PROBLEMS 6.1 Introduction 292 6.2 Solution of the Equations of Motion in Rectangular Coordinates 294 Example 6.1—Flow Between Parallel Plates 294 6.3 Alternative Solution Using a Shell Balance 301 Example 6.2—Shell Balance for Flow Between Parallel Plates 301 Example 6.3—Film Flow on a Moving Substrate 303 Example 6.4—Transient Viscous Diffusion of Momentum (COMSOL) 307 6.4 Poiseuille and Couette Flows in Polymer Processing 312 Example 6.5—The Single-Screw Extruder 313 Example 6.6—Flow Patterns in a Screw Extruder		of Mass Outflow	269
5.6 Differential Momentum Balances 5.7 Newtonian Stress Components in Cartesian Coordinates Example 5.8—Constant-Viscosity Momentum Balances in Terms of Velocity Gradients Example 5.9—Vector Form of Variable-Viscosity Momentum Balance Example 5.9—Vector Form of Variable-Viscosity Momentum Balance Problems for Chapter 5 CHAPTER 6—SOLUTION OF VISCOUS-FLOW PROBLEMS 6.1 Introduction 6.2 Solution of the Equations of Motion in Rectangular Coordinates Example 6.1—Flow Between Parallel Plates 6.3 Alternative Solution Using a Shell Balance Example 6.2—Shell Balance for Flow Between Parallel Plates Example 6.3—Film Flow on a Moving Substrate Example 6.4—Transient Viscous Diffusion of Momentum (COMSOL) 6.4 Poiseuille and Couette Flows in Polymer Processing Example 6.5—The Single-Screw Extruder Example 6.6—Flow Patterns in a Screw Extruder		Example 5.7—Alternative Derivation of the Continuity	
Example 5.8—Constant-Viscosity Momentum Balances in Terms of Velocity Gradients Example 5.9—Vector Form of Variable-Viscosity Momentum Balance Example 5.9—Vector Form of Variable-Viscosity Momentum Balance Problems for Chapter 5 CHAPTER 6—SOLUTION OF VISCOUS-FLOW PROBLEMS 6.1 Introduction 6.2 Solution of the Equations of Motion in Rectangular Coordinates Example 6.1—Flow Between Parallel Plates 6.3 Alternative Solution Using a Shell Balance Example 6.2—Shell Balance for Flow Between Parallel Plates Example 6.3—Film Flow on a Moving Substrate Example 6.4—Transient Viscous Diffusion of Momentum (COMSOL) 6.4 Poiseuille and Couette Flows in Polymer Processing Example 6.5—The Single-Screw Extruder Example 6.6—Flow Patterns in a Screw Extruder		Equation	270
Example 5.8—Constant-Viscosity Momentum Balances in Terms of Velocity Gradients 280 Example 5.9—Vector Form of Variable-Viscosity Momentum Balance 284 Problems for Chapter 5 285 CHAPTER 6—SOLUTION OF VISCOUS-FLOW PROBLEMS 6.1 Introduction 292 6.2 Solution of the Equations of Motion in Rectangular Coordinates 294 Example 6.1—Flow Between Parallel Plates 294 6.3 Alternative Solution Using a Shell Balance 301 Example 6.2—Shell Balance for Flow Between Parallel Plates 301 Example 6.3—Film Flow on a Moving Substrate 303 Example 6.4—Transient Viscous Diffusion of Momentum (COMSOL) 307 6.4 Poiseuille and Couette Flows in Polymer Processing 312 Example 6.5—The Single-Screw Extruder 313 Example 6.6—Flow Patterns in a Screw Extruder	5.6	Differential Momentum Balances	271
in Terms of Velocity Gradients Example 5.9—Vector Form of Variable-Viscosity Momentum Balance Problems for Chapter 5 CHAPTER 6—SOLUTION OF VISCOUS-FLOW PROBLEMS 6.1 Introduction 6.2 Solution of the Equations of Motion in Rectangular Coordinates Example 6.1—Flow Between Parallel Plates 6.3 Alternative Solution Using a Shell Balance Example 6.2—Shell Balance for Flow Between Parallel Plates Example 6.3—Film Flow on a Moving Substrate Example 6.4—Transient Viscous Diffusion of Momentum (COMSOL) 6.4 Poiseuille and Couette Flows in Polymer Processing Example 6.5—The Single-Screw Extruder Example 6.6—Flow Patterns in a Screw Extruder	5.7	Newtonian Stress Components in Cartesian Coordinates	274
Example 5.9—Vector Form of Variable-Viscosity Momentum Balance 284 Problems for Chapter 5 285 CHAPTER 6—SOLUTION OF VISCOUS-FLOW PROBLEMS 6.1 Introduction 292 6.2 Solution of the Equations of Motion in Rectangular Coordinates 294 Example 6.1—Flow Between Parallel Plates 294 6.3 Alternative Solution Using a Shell Balance Example 6.2—Shell Balance for Flow Between Parallel Plates 301 Example 6.3—Film Flow on a Moving Substrate Example 6.4—Transient Viscous Diffusion of Momentum (COMSOL) 307 6.4 Poiseuille and Couette Flows in Polymer Processing Example 6.5—The Single-Screw Extruder 313 Example 6.6—Flow Patterns in a Screw Extruder		Example 5.8—Constant-Viscosity Momentum Balances	
Momentum Balance 284 Problems for Chapter 5 285 CHAPTER 6—SOLUTION OF VISCOUS-FLOW PROBLEMS 6.1 Introduction 292 6.2 Solution of the Equations of Motion in Rectangular Coordinates 294 Example 6.1—Flow Between Parallel Plates 294 6.3 Alternative Solution Using a Shell Balance 301 Example 6.2—Shell Balance for Flow Between Parallel Plates 301 Example 6.3—Film Flow on a Moving Substrate 303 Example 6.4—Transient Viscous Diffusion of Momentum (COMSOL) 307 6.4 Poiseuille and Couette Flows in Polymer Processing 312 Example 6.5—The Single-Screw Extruder 313 Example 6.6—Flow Patterns in a Screw Extruder		in Terms of Velocity Gradients	280
CHAPTER 6—SOLUTION OF VISCOUS-FLOW PROBLEMS 6.1 Introduction 292 6.2 Solution of the Equations of Motion in Rectangular Coordinates 294 Example 6.1—Flow Between Parallel Plates 294 6.3 Alternative Solution Using a Shell Balance 301 Example 6.2—Shell Balance for Flow Between Parallel Plates 301 Example 6.3—Film Flow on a Moving Substrate 303 Example 6.4—Transient Viscous Diffusion of Momentum (COMSOL) 307 6.4 Poiseuille and Couette Flows in Polymer Processing 312 Example 6.5—The Single-Screw Extruder 313 Example 6.6—Flow Patterns in a Screw Extruder		Example 5.9—Vector Form of Variable-Viscosity	
CHAPTER 6—SOLUTION OF VISCOUS-FLOW PROBLEMS 6.1 Introduction 292 6.2 Solution of the Equations of Motion in Rectangular Coordinates 294 Example 6.1—Flow Between Parallel Plates 294 6.3 Alternative Solution Using a Shell Balance 301 Example 6.2—Shell Balance for Flow Between Parallel Plates 301 Example 6.3—Film Flow on a Moving Substrate 303 Example 6.4—Transient Viscous Diffusion of Momentum (COMSOL) 307 6.4 Poiseuille and Couette Flows in Polymer Processing 312 Example 6.5—The Single-Screw Extruder 313 Example 6.6—Flow Patterns in a Screw Extruder		Momentum Balance	284
6.1 Introduction 6.2 Solution of the Equations of Motion in Rectangular Coordinates Example 6.1—Flow Between Parallel Plates 6.3 Alternative Solution Using a Shell Balance Example 6.2—Shell Balance for Flow Between Parallel Plates 101 Example 6.3—Film Flow on a Moving Substrate Example 6.4—Transient Viscous Diffusion of Momentum (COMSOL) 102 103 104 105 105 106 107 107 108 109 109 109 109 109 109 109		Problems for Chapter 5	285
6.2 Solution of the Equations of Motion in Rectangular Coordinates Example 6.1—Flow Between Parallel Plates 294 6.3 Alternative Solution Using a Shell Balance Example 6.2—Shell Balance for Flow Between Parallel Plates 301 Example 6.3—Film Flow on a Moving Substrate Example 6.4—Transient Viscous Diffusion of Momentum (COMSOL) 307 6.4 Poiseuille and Couette Flows in Polymer Processing Example 6.5—The Single-Screw Extruder 313 Example 6.6—Flow Patterns in a Screw Extruder	СНАРТІ	ER 6—SOLUTION OF VISCOUS-FLOW PROBLEMS	
6.2 Solution of the Equations of Motion in Rectangular Coordinates Example 6.1—Flow Between Parallel Plates 294 6.3 Alternative Solution Using a Shell Balance Example 6.2—Shell Balance for Flow Between Parallel Plates 301 Example 6.3—Film Flow on a Moving Substrate Example 6.4—Transient Viscous Diffusion of Momentum (COMSOL) 307 6.4 Poiseuille and Couette Flows in Polymer Processing Example 6.5—The Single-Screw Extruder 313 Example 6.6—Flow Patterns in a Screw Extruder	6.1	Introduction	292
Coordinates Example 6.1—Flow Between Parallel Plates 6.3 Alternative Solution Using a Shell Balance Example 6.2—Shell Balance for Flow Between Parallel Plates Output Plates 10301 Example 6.3—Film Flow on a Moving Substrate Example 6.4—Transient Viscous Diffusion of Momentum (COMSOL) 10501 Momentum (COMSOL) 10502 10503 105			
Example 6.1—Flow Between Parallel Plates 294 6.3 Alternative Solution Using a Shell Balance 301 Example 6.2—Shell Balance for Flow Between Parallel Plates 301 Example 6.3—Film Flow on a Moving Substrate 303 Example 6.4—Transient Viscous Diffusion of Momentum (COMSOL) 307 6.4 Poiseuille and Couette Flows in Polymer Processing 312 Example 6.5—The Single-Screw Extruder 313 Example 6.6—Flow Patterns in a Screw Extruder	0.2	<u>.</u>	294
6.3 Alternative Solution Using a Shell Balance Example 6.2—Shell Balance for Flow Between Parallel Plates 301 Example 6.3—Film Flow on a Moving Substrate Example 6.4—Transient Viscous Diffusion of Momentum (COMSOL) 307 6.4 Poiseuille and Couette Flows in Polymer Processing Example 6.5—The Single-Screw Extruder 313 Example 6.6—Flow Patterns in a Screw Extruder			
Example 6.2—Shell Balance for Flow Between Parallel Plates 301 Example 6.3—Film Flow on a Moving Substrate 303 Example 6.4—Transient Viscous Diffusion of Momentum (COMSOL) 307 6.4 Poiseuille and Couette Flows in Polymer Processing 312 Example 6.5—The Single-Screw Extruder 313 Example 6.6—Flow Patterns in a Screw Extruder	6.3	•	
Plates 301 Example 6.3—Film Flow on a Moving Substrate 303 Example 6.4—Transient Viscous Diffusion of Momentum (COMSOL) 307 6.4 Poiseuille and Couette Flows in Polymer Processing 312 Example 6.5—The Single-Screw Extruder 313 Example 6.6—Flow Patterns in a Screw Extruder	0.0	9	301
Example 6.3—Film Flow on a Moving Substrate Example 6.4—Transient Viscous Diffusion of Momentum (COMSOL) 6.4 Poiseuille and Couette Flows in Polymer Processing Example 6.5—The Single-Screw Extruder Example 6.6—Flow Patterns in a Screw Extruder		•	301
Example 6.4—Transient Viscous Diffusion of Momentum (COMSOL) 6.4 Poiseuille and Couette Flows in Polymer Processing Example 6.5—The Single-Screw Extruder Example 6.6—Flow Patterns in a Screw Extruder			
Momentum (COMSOL) 307 6.4 Poiseuille and Couette Flows in Polymer Processing 312 Example 6.5—The Single-Screw Extruder 313 Example 6.6—Flow Patterns in a Screw Extruder			000
6.4 Poiseuille and Couette Flows in Polymer Processing Example 6.5—The Single-Screw Extruder Example 6.6—Flow Patterns in a Screw Extruder		•	307
Example 6.5—The Single-Screw Extruder 313 Example 6.6—Flow Patterns in a Screw Extruder	6.4	· · · · · ·	
Example 6.6—Flow Patterns in a Screw Extruder	V	· ·	
•			310
		(COMSOL)	318

	α
v	Contents

6.5	Solution of the Equations of Motion in Cylindrical Coordinates	322
	Example 6.7—Flow Through an Annular Die	322
c c	Example 6.8—Spinning a Polymeric Fiber	325
6.6	Solution of the Equations of Motion in Spherical	207
	Coordinates Example 6.0 Analysis of a Cons and Plate Phaemeter	$\frac{327}{328}$
	Example 6.9—Analysis of a Cone-and-Plate Rheometer Problems for Chapter 6	333
	1 Toblems for Chapter o	555
СНАРТЕ	ER 7—LAPLACE'S EQUATION, IRROTATIONAL AND POROUS-MEDIA FLOWS	
7.1	Introduction	354
7.2	Rotational and Irrotational Flows	356
	Example 7.1—Forced and Free Vortices	359
7.3	Steady Two-Dimensional Irrotational Flow	361
7.4	Physical Interpretation of the Stream Function	364
7.5	Examples of Planar Irrotational Flow	366
	Example 7.2—Stagnation Flow	369
	Example 7.3—Combination of a Uniform Stream and	a=4
	a Line Sink (C)	371
7.0	Example 7.4—Flow Patterns in a Lake (COMSOL)	373
7.6	Axially Symmetric Irrotational Flow	378
7.7	Uniform Streams and Point Sources	380
7.8 7.9	Doublets and Flow Past a Sphere Single Phase Flow in a Percus Medium	$\frac{384}{387}$
1.9	Single-Phase Flow in a Porous Medium Example 7.5—Underground Flow of Water	388
7.10	Two-Phase Flow in Porous Media	390
7.10	Wave Motion in Deep Water	396
1.11	Problems for Chapter 7	400
	1100101110 101 0111101011	100
СНАРТЕ	ER 8—BOUNDARY-LAYER AND OTHER NEARLY UNIDIRECTIONAL FLOWS	
8.1	Introduction	414
8.2	Simplified Treatment of Laminar Flow Past a Flat Plate	415
	Example 8.1—Flow in an Air Intake (C)	420
8.3	Simplification of the Equations of Motion	422
8.4	Blasius Solution for Boundary-Layer Flow	425
8.5	Turbulent Boundary Layers	428
	Example 8.2—Laminar and Turbulent Boundary	
	Layers Compared	429
8.6	Dimensional Analysis of the Boundary-Layer Problem	430

		Contents	xi
	8.7	Boundary-Layer Separation	433
		Example 8.3—Boundary-Layer Flow Between Parallel	
		Plates (COMSOL Library)	435
		Example 8.4—Entrance Region for Laminar Flow	
		Between Flat Plates	440
	8.8	The Lubrication Approximation	442
		Example 8.5—Flow in a Lubricated Bearing (COMSOL)	448
	8.9	Polymer Processing by Calendering	450
		Example 8.6—Pressure Distribution in a Calendered	
		Sheet	454
	8.10	Thin Films and Surface Tension	456
		Problems for Chapter 8	459
CE	IAPTE:	R 9—TURBULENT FLOW	
	9.1	Introduction	473
	9.1	Example 9.1—Numerical Illustration of a Reynolds	410
		Stress Term	479
	9.2	Physical Interpretation of the Reynolds Stresses	480
	9.3	Mixing-Length Theory	481
	9.4	Determination of Eddy Kinematic Viscosity and	401
	3.4	Mixing Length	484
	9.5	Velocity Profiles Based on Mixing-Length Theory	486
	9.0	Example 9.2—Investigation of the von Kármán	400
		Hypothesis	487
	9.6	v -	
		The Universal Velocity Profile for Smooth Pipes	488
	9.7	Friction Factor in Terms of Reynolds Number for Smooth	400
		Pipes	490
	0.0	Example 9.3—Expression for the Mean Velocity	491
	9.8	Thickness of the Laminar Sublayer	492
	9.9	Velocity Profiles and Friction Factor for Rough Pipe	494
	9.10	Blasius-Type Law and the Power-Law Velocity Profile	495
	9.11	A Correlation for the Reynolds Stresses	496
	9.12	Computation of Turbulence by the k/ε Method	499
		Example 9.4—Flow Through an Orifice Plate (COMSOL)	501
		Example 9.5—Turbulent Jet Flow (COMSOL)	505
	9.13	Analogies Between Momentum and Heat Transfer	509
		Example 9.6—Evaluation of the Momentum/Heat-	
		Transfer Analogies	511
	9.14	Turbulent Jets	513
		Problems for Chapter 9	521

xii Contents

СНАРТЕ	ER 10—BUBBLE MOTION, TWO-PHASE FLOW, AND FLUIDIZATION	
10.1	Introduction	531
10.2	Rise of Bubbles in Unconfined Liquids	531
	Example 10.1—Rise Velocity of Single Bubbles	536
10.3	Pressure Drop and Void Fraction in Horizontal Pipes	536
	Example 10.2—Two-Phase Flow in a Horizontal Pipe	541
10.4	Two-Phase Flow in Vertical Pipes	543
	Example 10.3—Limits of Bubble Flow	546
	Example 10.4—Performance of a Gas-Lift Pump	550
	Example 10.5—Two-Phase Flow in a Vertical Pipe	553
10.5	Flooding	555
10.6	Introduction to Fluidization	559
10.7	Bubble Mechanics	561
10.8	Bubbles in Aggregatively Fluidized Beds	566
	Example 10.6—Fluidized Bed with Reaction (C)	572
	Problems for Chapter 10	575
СНАРТЕ	ER 11—NON-NEWTONIAN FLUIDS	
11.1	Introduction	591
11.2	Classification of Non-Newtonian Fluids	592
11.3	Constitutive Equations for Inelastic Viscous Fluids	595
	Example 11.1—Pipe Flow of a Power-Law Fluid	600
	Example 11.2—Pipe Flow of a Bingham Plastic	604
	Example 11.3—Non-Newtonian Flow in a Die	
	(COMSOL Library)	606
11.4	Constitutive Equations for Viscoelastic Fluids	613
11.5	Response to Oscillatory Shear	620
11.6	Characterization of the Rheological Properties of Fluids	623
	Example 11.4—Proof of the Rabinowitsch Equation	624
	Example 11.5—Working Equation for a Coaxial-	
	Cylinder Rheometer: Newtonian Fluid	628
	Problems for Chapter 11	630
СНАРТЕ	ER 12—MICROFLUIDICS AND ELECTROKINETIC FLOW EFFECTS	
12.1	Introduction	639
12.2	Physics of Microscale Fluid Mechanics	640
12.3	Pressure-Driven Flow Through Microscale Tubes	641
	Example 12.1—Calculation of Reynolds Numbers	641
12.4	Mixing, Transport, and Dispersion	642

	Contents	xiii
12.5	Species, Energy, and Charge Transport	644
12.6	The Electrical Double Layer and Electrokinetic Phenomena Example 12.2—Relative Magnitudes of Electroosmotic	647
	and Pressure-Driven Flows	648
	Example 12.3—Electroosmotic Flow Around a Particle Example 12.4—Electroosmosis in a Microchannel	653
	(COMSOL)	653
	Example 12.5—Electroosmotic Switching in a	
	Branched Microchannel (COMSOL)	657
12.7	Measuring the Zeta Potential	659
	Example 12.6—Magnitude of Typical Streaming	
	Potentials	660
12.8	Electroviscosity	661
12.9	Particle and Macromolecule Motion in Microfluidic Channels Example 12.7—Gravitational and Magnetic Settling	661
	of Assay Beads	662
	Problems for Chapter 12	666
СНАРТЕ	R 13—AN INTRODUCTION TO COMPUTATIONAL FLUID DYNAMICS AND FLOWLAB	
13.1	Introduction and Motivation	671
13.2	Numerical Methods	673
13.3	Learning CFD by Using FlowLab	682
13.4	Practical CFD Examples	686
	Example 13.1—Developing Flow in a Pipe	
	Entrance Region (FlowLab)	687
	Example 13.2—Pipe Flow Through a Sudden	
	Expansion (FlowLab)	690
	Example 13.3—A Two-Dimensional Mixing Junction	coo
	(FlowLab) Example 13.4—Flow Over a Cylinder (FlowLab)	$692 \\ 696$
	References for Chapter 13	702
	References for Chapter 13	102
СНАРТЕ	R 14—COMSOL (FEMLAB) MULTIPHYSICS FOR SOLVING FLUID MECHANICS PROBLEMS	
14.1	Introduction to COMSOL	703
$14.1 \\ 14.2$	How to Run COMSOL	705 705
17.4	Example 14.1—Flow in a Porous Medium with an	100
	Obstruction (COMSOL)	705
14.3	Draw Mode	719
14.4	Solution and Related Modes	724

xiv Contents

	Mechanics Problems Solvable by COMSOL ems for Chapter 14	725 730
APPENDIX A:	USEFUL MATHEMATICAL RELATIONSHIPS	731
APPENDIX B:	ANSWERS TO THE TRUE/FALSE ASSERTIONS	737
APPENDIX C:	SOME VECTOR AND TENSOR OPERATIONS	740
INDEX		743
THE AUTHORS	S	753

THIS text has evolved from a need for a single volume that embraces a wide range of topics in fluid mechanics. The material consists of two parts—four chapters on *macroscopic* or relatively large-scale phenomena, followed by ten chapters on *microscopic* or relatively small-scale phenomena. Throughout, I have tried to keep in mind topics of industrial importance to the chemical engineer. The scheme is summarized in the following list of chapters.

Part I—Macroscopic Fluid Mechanics

- 1. Introduction to Fluid Mechanics
- 2. Mass, Energy, and Momentum Balances
- 3. Fluid Friction in Pipes
- 4. Flow in Chemical Engineering Equipment

Part II—Microscopic Fluid Mechanics

- 5. Differential Equations of Fluid Mechanics
- 6. Solution of Viscous-Flow Problems
- 7. Laplace's Equation, Irrotational and Porous-Media Flows
- 8. Boundary-Layer and Other Nearly Unidirectional Flows
- 9. Turbulent Flow
- 10. Bubble Motion, Two-Phase Flow, and Fluidization

- 11. Non-Newtonian Fluids
- 12. Microfluidics and Electrokinetic Flow Effects
- 13. An Introduction to Computational Fluid Dynamics and FlowLab
- COMSOL (FEMLAB) Multiphysics for Solving Fluid Mechanics Problems

In our experience, an undergraduate fluid mechanics course can be based on Part I plus selected parts of Part II, and a graduate course can be based on much of Part II, supplemented perhaps by additional material on topics such as approximate methods and stability.

Second edition. I have attempted to bring the book up to date by the major addition of Chapters 12, 13, and 14—one on microfluidics and two on CFD (computational fluid dynamics). The choice of software for the CFD presented a difficulty; for various reasons, I selected FlowLab and COMSOL Multiphysics, but there was no intention of "promoting" these in favor of other excellent CFD programs.¹ The use of CFD examples in the classroom really makes the subject

 $^{^1}$ The software name "FEMLAB" was changed to "COMSOL Multiphysics" in September 2005, the first release under the new name being COMSOL 3.2.

xvi Preface

come "alive," because the previous restrictive necessities of "nice" geometries and constant physical properties, etc., can now be lifted. Chapter 9, on turbulence, has also been extensively rewritten; here again, CFD allows us to venture beyond the usual flow in a pipe or between parallel plates and to investigate further practical situations such as turbulent mixing and recirculating flows.

Example problems. There is an average of about six completely worked examples in each chapter, including several involving COMSOL (dispersed throughout Part II) and FlowLab (all in Chapter 13). The end of each example is marked by a small, hollow square: \square . All the COMSOL examples have been run on a Macintosh G4 computer using FEMLAB 3.1, but have also been checked on a PC; those using a PC or other releases of COMSOL/FEMLAB may encounter slightly different windows than those reproduced here. The format for each COMSOL example is: (a) problem statement, (b) details of COMSOL implementation, and (c) results and discussion (however, item (b) can easily be skipped for those interested only in the results).

The numerous end-of-chapter problems have been classified roughly as easy (E), moderate (M), or difficult/lengthy (D). The University of Cambridge has given permission—kindly endorsed by Professor J.F. Davidson, F.R.S.—for several of their chemical engineering examination problems to be reproduced in original or modified form, and these have been given the additional designation of "(C)".

Acknowledgments. I gratefully acknowledge the written contributions of my former Michigan colleague Stacy Birmingham (non-Newtonian fluids), Brian Kirby of Cornell University (microfluidics), and Chi-Yang Cheng of Fluent, Inc. (FlowLab). Although I wrote most of the COMSOL examples, I have had great help and cooperation from COMSOL Inc. and the following personnel in particular—Philip Byrne, Bjorn Sjodin, Ed Fontes, Peter Georen, Olof Hernell, Johan Linde, and Rémi Magnard. At Fluent, Inc., Shane Moeykens was instrumental in identifying Chi-Yang Cheng as the person best suited to write the FlowLab chapter. Courtney Esposito and Jordan Schmidt of The MathWorks kindly helped me with MATLAB, needed for the earlier 2.3 version of FEMLAB.

I appreciate the assistance of several other friends and colleagues, including Nitin Anturkar, Stuart Churchill, John Ellis, Kevin Ellwood, Scott Fogler, Leenaporn Jongpaiboonkit, Lisa Keyser, Kartic Khilar, Ronald Larson, Susan Montgomery, Donald Nicklin, the late Margaret Sansom, Michael Solomon, Sandra Swisher, Rasin Tek, Robert Ziff, and my wife Mary Ann Gibson Wilkes. Also very helpful were Bernard Goodwin, Elizabeth Ryan, and Michelle Housley at Prentice Hall PTR, and my many students and friends at the University of Michigan and Chulalongkorn University in Bangkok. Others are acknowledged in specific literature citations.

Further information. The website http://www.engin.umich.edu/~fmche is maintained as a "bulletin board" for giving additional information about the

book—hints for problem solutions, *errata*, how to contact the authors, etc.—as proves desirable. My own Internet address is wilkes@umich.edu. The text was composed on a Power Macintosh G4 computer using the TEXtures "typesetting" program. Eleven-point type was used for the majority of the text. Most of the figures were constructed using MacDraw Pro, Excel, and KaleidaGraph.

Professor Terence Fox, to whom this book is dedicated, was a Cambridge engineering graduate who worked from 1933 to 1937 at Imperial Chemical Industries Ltd., Billingham, Yorkshire. Returning to Cambridge, he taught engineering from 1937 to 1946 before being selected to lead the Department of Chemical Engineering at the University of Cambridge during its formative years after the end of World War II. As a scholar and a gentleman, Fox was a shy but exceptionally brilliant person who had great insight into what was important and who quickly brought the department to a preeminent position. He succeeded in combining an industrial perspective with intellectual rigor. Fox relinquished the leadership of the department in 1959, after he had secured a permanent new building for it (carefully designed in part by himself).




T.R.C. Fox

Fox was instrumental in bringing Peter Danckwerts, Kenneth Denbigh, John Davidson, and others into the department. He also accepted me in 1956 as a junior faculty member, and I spent four good years in the Cambridge University Department of Chemical Engineering. Danckwerts subsequently wrote an appreciation² of Fox's talents, saying, with almost complete accuracy: "Fox instigated no research and published nothing." How times have changed—today, unless he were known personally, his résumé would probably be cast aside and he would stand little chance of being hired, let alone of receiving tenure! However, his lectures, meticulously written handouts, enthusiasm, genius, and friendship were a great inspiration to me, and I have much pleasure in

acknowledging his positive impact on my career.

James O. Wilkes August 18, 2005

² P.V. Danckwerts, "Chemical engineering comes to Cambridge," The Cambridge Review, pp. 53–55, February 28, 1983.



Some Greek Letters

α	alpha	ν	nu
β	beta	ξ,Ξ	xi
γ, Γ	gamma	0	omicron
δ, Δ	delta	π, ϖ, Π	pi
ϵ, ε	epsilon	ho, arrho	rho
ζ	zeta	$\sigma, \varsigma, \Sigma$	$_{ m sigma}$
η	eta	au	tau
$\theta, \vartheta, \Theta$	theta	v,Υ	upsilon
ι	iota	$\phi, arphi, \Phi$	phi
κ	kappa	χ	chi
λ, Λ	lambda	ψ,Ψ	psi
μ	mu	ω,Ω	omega

INTRODUCTION TO FLUID MECHANICS

1.1 Fluid Mechanics in Chemical Engineering

A knowledge of fluid mechanics is essential for the chemical engineer because the majority of chemical-processing operations are conducted either partly or totally in the fluid phase. Examples of such operations abound in the biochemical, chemical, energy, fermentation, materials, mining, petroleum, pharmaceuticals, polymer, and waste-processing industries.

There are two principal reasons for placing such an emphasis on fluids. First, at typical operating conditions, an enormous number of materials normally exist as gases or liquids, or can be transformed into such phases. Second, it is usually more efficient and cost-effective to work with fluids in contrast to solids. Even some operations with solids can be conducted in a quasi-fluidlike manner; examples are the fluidized-bed catalytic refining of hydrocarbons, and the long-distance pipelining of coal particles using water as the agitating and transporting medium.


Although there is inevitably a significant amount of theoretical development, almost *all* the material in this book has some application to chemical processing and other important practical situations. Throughout, we shall endeavor to present an understanding of the *physical* behavior involved; only then is it really possible to comprehend the accompanying theory and equations.

1.2 General Concepts of a Fluid

We must begin by responding to the question, "What is a fluid?" Broadly speaking, a fluid is a substance that will deform continuously when it is subjected to a tangential or shear force, much as a similar type of force is exerted when a water-skier skims over the surface of a lake or butter is spread on a slice of bread. The rate at which the fluid deforms continuously depends not only on the magnitude of the applied force but also on a property of the fluid called its viscosity or resistance to deformation and flow. Solids will also deform when sheared, but a position of equilibrium is soon reached in which elastic forces induced by the deformation of the solid exactly counterbalance the applied shear force, and further deformation ceases.

4 Chapter 1—Introduction to Fluid Mechanics

A simple apparatus for shearing a fluid is shown in Fig. 1.1. The fluid is contained between two concentric cylinders; the outer cylinder is stationary, and the inner one (of radius R) is rotated steadily with an angular velocity ω . This shearing motion of a fluid can continue indefinitely, provided that a source of energy—supplied by means of a torque here—is available for rotating the inner cylinder. The diagram also shows the resulting velocity profile; note that the velocity in the direction of rotation varies from the peripheral velocity $R\omega$ of the inner cylinder down to zero at the outer stationary cylinder, these representing typical no-slip conditions at both locations. However, if the intervening space is filled with a solid—even one with obvious elasticity, such as rubber—only a limited rotation will be possible before a position of equilibrium is reached, unless, of course, the torque is so high that slip occurs between the rubber and the cylinder.



(a) Side elevation

(b) Plan of section across A-A (not to scale)

Fig. 1.1 Shearing of a fluid.

There are various classes of fluids. Those that behave according to nice and obvious simple laws, such as water, oil, and air, are generally called *Newtonian* fluids. These fluids exhibit constant viscosity but, under typical processing conditions, virtually no elasticity. Fortunately, a very large number of fluids of interest to the chemical engineer exhibit Newtonian behavior, which will be assumed throughout the book, except in Chapter 11, which is devoted to the study of non-Newtonian fluids.

A fluid whose viscosity is not constant (but depends, for example, on the intensity to which it is being sheared), or which exhibits significant elasticity, is termed non-Newtonian. For example, several polymeric materials subject to deformation can "remember" their recent molecular configurations, and in attempting to recover their recent states, they will exhibit elasticity in addition to viscosity. Other fluids, such as drilling mud and toothpaste, behave essentially as solids and

will not flow when subject to *small* shear forces, but *will* flow readily under the influence of *high* shear forces.

Fluids can also be broadly classified into two main categories—liquids and gases. Liquids are characterized by relatively high densities and viscosities, with molecules close together; their volumes tend to remain constant, roughly independent of pressure, temperature, or the size of the vessels containing them. Gases, on the other hand, have relatively low densities and viscosities, with molecules far apart; generally, they will rapidly tend to fill the container in which they are placed. However, these two states—liquid and gaseous—represent but the two extreme ends of a continuous spectrum of possibilities.




Fig. 1.2 When does a liquid become a gas?

The situation is readily illustrated by considering a fluid that is initially a gas at point G on the pressure/temperature diagram shown in Fig. 1.2. By increasing the pressure, and perhaps lowering the temperature, the vapor-pressure curve is soon reached and crossed, and the fluid condenses and apparently becomes a liquid at point L. By continuously adjusting the pressure and temperature so that the clockwise path is followed, and circumnavigating the critical point C in the process, the fluid is returned to G, where it is presumably once more a gas. But where does the transition from liquid at L to gas at G occur? The answer is at no single point, but rather that the change is a continuous and gradual one, through a whole spectrum of intermediate states.

1.3 Stresses, Pressure, Velocity, and the Basic Laws

Stresses. The concept of a *force* should be readily apparent. In fluid mechanics, a force per unit area, called a *stress*, is usually found to be a more convenient and versatile quantity than the force itself. Further, when considering a specific surface, there are two types of stresses that are particularly important.

1. The first type of stress, shown in Fig. 1.3(a), acts perpendicularly to the surface and is therefore called a normal stress; it will be tensile or compressive, depending on whether it tends to stretch or to compress the fluid on which it acts. The normal stress equals F/A, where F is the normal force and A is the area of the surface on which it acts. The dotted outlines show the volume changes caused

by deformation. In fluid mechanics, *pressure* is usually the most important type of *compressive* stress, and will shortly be discussed in more detail.

2. The second type of stress, shown in Fig. 1.3(b), acts tangentially to the surface; it is called a shear stress τ , and equals F/A, where F is the tangential force and A is the area on which it acts. Shear stress is transmitted through a fluid by interaction of the molecules with one another. A knowledge of the shear stress is very important when studying the flow of viscous Newtonian fluids. For a given rate of deformation, measured by the time derivative $d\gamma/dt$ of the small angle of deformation γ , the shear stress τ is directly proportional to the viscosity of the fluid (see Fig. 1.3(b)).




Fig. 1.3(a) Tensile and compressive normal stresses F/A, acting on a cylinder, causing elongation and shrinkage, respectively.




Fig. 1.3(b) Shear stress $\tau = F/A$, acting on a rectangular parallelepiped, shown in cross section, causing a deformation measured by the angle γ (whose magnitude is exaggerated here).

Pressure. In virtually all *hydrostatic* situations—those involving fluids at rest—the fluid molecules are in a state of *compression*. For example, for the swimming pool whose cross section is depicted in Fig. 1.4, this compression at a typical point P is caused by the downwards gravitational weight of the water *above* point P. The degree of compression is measured by a scalar, p—the *pressure*.

A small inflated spherical balloon pulled down from the surface and tethered at the bottom by a weight will still retain its spherical shape (apart from a small distortion at the point of the tether), but will be diminished in size, as in Fig. 1.4(a). It is apparent that there must be forces acting *normally inward* on the

surface of the balloon, and that these must essentially be uniform for the shape to remain spherical, as in Fig. 1.4(b).




Fig. 1.4 (a) Balloon submerged in a swimming pool; (b) enlarged view of the compressed balloon, with pressure forces acting on it.

Although the pressure p is a scalar, it typically appears in tandem with an area A (assumed small enough so that the pressure is uniform over it). By definition of pressure, the surface experiences a normal compressive force F = pA. Thus, pressure has units of a force per unit area—the same as a stress.

The value of the pressure at a point is *independent* of the orientation of any area associated with it, as can be deduced with reference to a differentially small wedge-shaped element of the fluid, shown in Fig. 1.5.




Fig. 1.5 Equilibrium of a wedge of fluid.

Due to the pressure there are three forces, $p_A dA$, $p_B dB$, and $p_C dC$, that act on the three rectangular faces of areas dA, dB, and dC. Since the wedge is not moving, equate the two forces acting on it in the horizontal or x direction, noting that $p_A dA$ must be resolved through an angle $(\pi/2 - \theta)$ by multiplying it by $\cos(\pi/2 - \theta) = \sin \theta$:

$$p_A dA \sin \theta = p_C dC. \tag{1.1}$$

The vertical force $p_B dB$ acting on the bottom surface is omitted from Eqn. (1.1) because it has no component in the x direction. The horizontal pressure forces

acting in the y direction on the two triangular faces of the wedge are also omitted, since again these forces have no effect in the x direction. From geometrical considerations, areas dA and dC are related by:

$$dC = dA\sin\theta. \tag{1.2}$$

These last two equations yield:

$$p_A = p_C, (1.3)$$

verifying that the pressure is independent of the orientation of the surface being considered. A force balance in the z direction leads to a similar result, $p_A = p_B$.

For moving fluids, the normal stresses include both a pressure and extra stresses caused by the motion of the fluid, as discussed in detail in Section 5.6.

The amount by which a certain pressure exceeds that of the atmosphere is termed the *gauge* pressure, the reason being that many common pressure gauges are really *differential* instruments, reading the difference between a required pressure and that of the surrounding atmosphere. *Absolute* pressure equals the gauge pressure plus the atmospheric pressure.

Velocity. Many problems in fluid mechanics deal with the *velocity* of the fluid at a point, equal to the rate of change of the position of a fluid particle with time, thus having both a magnitude and a direction. In some situations, particularly those treated from the *macroscopic* viewpoint, as in Chapters 2, 3, and 4, it sometimes suffices to ignore variations of the velocity with position. In other cases—particularly those treated from the *microscopic* viewpoint, as in Chapter 6 and later—it is invariably essential to consider variations of velocity with position.




Fig. 1.6 Fluid passing through an area A: (a) Uniform velocity, (b) varying velocity.

Velocity is not only important in its own right, but leads immediately to three fluxes or flow rates. Specifically, if u denotes a uniform velocity (not varying with position):

Actually, a force balance in the z direction demands that the gravitational weight of the wedge be considered, which is proportional to the volume of the wedge. However, the pressure forces are proportional to the areas of the faces. It can readily be shown that the volume-to-area effect becomes vanishingly small as the wedge becomes infinitesimally small, so that the gravitational weight is inconsequential.

- 1. If the fluid passes through a plane of area A normal to the direction of the velocity, as shown in Fig. 1.6, the corresponding *volumetric* flow rate of fluid through the plane is Q = uA.
- 2. The corresponding mass flow rate is $m = \rho Q = \rho u A$, where ρ is the (constant) fluid density. The alternative notation with an overdot, \dot{m} , is also used.
- 3. When velocity is multiplied by mass it gives momentum, a quantity of prime importance in fluid mechanics. The corresponding momentum flow rate passing through the area A is $\dot{\mathcal{M}} = mu = \rho u^2 A$.

If u and/or ρ should vary with position, as in Fig. 1.6(b), the corresponding expressions will be seen later to involve *integrals* over the area A: $Q = \int_A u \, dA$, $m = \int_A \rho u \, dA$, $\dot{\mathcal{M}} = \int_A \rho u^2 \, dA$.

Basic laws. In principle, the *laws* of fluid mechanics can be stated simply, and—in the absence of relativistic effects—amount to conservation of mass, energy, and momentum. When applying these laws, the procedure is first to identify a system, its boundary, and its surroundings; and second, to identify how the system interacts with its surroundings. Refer to Fig. 1.7 and let the quantity X represent either mass, energy, or momentum. Also recognize that X may be added from the surroundings and transported into the system by an amount $X_{\rm in}$ across the boundary, and may likewise be removed or transported out of the system to the surroundings by an amount $X_{\rm out}$.




Fig. 1.7 A system and transports to and from it.

The general conservation law gives the increase $\Delta X_{\mathrm{system}}$ in the X-content of the system as:

$$X_{\rm in} - X_{\rm out} = \Delta X_{\rm system}.$$
 (1.4a)

Although this basic law may appear intuitively obvious, it applies only to a very restricted selection of properties X. For example, it is not generally true if X is another extensive property such as volume, and is quite meaningless if X is an intensive property such as pressure or temperature.

In certain cases, where X^i is the mass of a definite chemical species i, we may also have an amount of creation X^i_{created} or destruction $X^i_{\text{destroyed}}$ due to chemical reaction, in which case the general law becomes:

$$X_{\rm in}^i - X_{\rm out}^i + X_{\rm created}^i - X_{\rm destroyed}^i = \Delta X_{\rm system}^i. \tag{1.4b}$$

The conservation law will be discussed further in Section 2.1, and is of such fundamental importance that in various guises it will find numerous applications throughout all of this text.

To solve a physical problem, the following information concerning the fluid is also usually needed:

- 1. The physical properties of the fluid involved, as discussed in Section 1.4.
- 2. For situations involving fluid flow, a constitutive equation for the fluid, which relates the various stresses to the flow pattern.

1.4 Physical Properties—Density, Viscosity, and Surface Tension

There are three physical properties of fluids that are particularly important: density, viscosity, and surface tension. Each of these will be defined and viewed briefly in terms of molecular concepts, and their dimensions will be examined in terms of mass, length, and time (M, L, and T). The physical properties depend primarily on the particular fluid. For liquids, viscosity also depends strongly on the temperature; for gases, viscosity is approximately proportional to the square root of the absolute temperature. The density of gases depends almost directly on the absolute pressure; for most other cases, the effect of pressure on physical properties can be disregarded.

Typical processes often run almost isothermally, and in these cases the effect of temperature can be ignored. Except in certain special cases, such as the flow of a compressible gas (in which the density is not constant) or a liquid under a very high shear rate (in which viscous dissipation can cause significant internal heating), or situations involving exothermic or endothermic reactions, we shall ignore any variation of physical properties with pressure and temperature.

Densities of liquids. Density depends on the mass of an individual molecule and the number of such molecules that occupy a unit of volume. For liquids, density depends primarily on the particular liquid and, to a much smaller extent, on its temperature. Representative densities of liquids are given in Table 1.1.² (See Eqns. (1.9)–(1.11) for an explanation of the specific gravity and coefficient of thermal expansion columns.) The accuracy of the values given in Tables 1.1–1.6 is adequate for the calculations needed in this text. However, if highly accurate values are needed, particularly at extreme conditions, then specialized information should be sought elsewhere.

Density. The *density* ρ of a fluid is defined as its mass per unit volume, and indicates its inertia or resistance to an accelerating force. Thus:

$$\rho = \frac{\text{mass}}{\text{volume}} \ [=] \ \frac{\text{M}}{\text{L}^3},\tag{1.5}$$

² The values given in Tables 1.1, 1.3, 1.4, 1.5, and 1.6 are based on information given in J.H. Perry, ed., Chemical Engineers' Handbook, 3rd ed., McGraw-Hill, New York, 1950.

in which the notation "[=]" is consistently used to indicate the *dimensions* of a quantity.³ It is usually understood in Eqn. (1.5) that the volume is chosen so that it is neither so small that it has no chance of containing a representative selection of molecules nor so large that (in the case of gases) changes of pressure cause significant changes of density throughout the volume. A medium characterized by a density is called a *continuum*, and follows the classical laws of mechanics—including Newton's law of motion, as described in this book.

Liquid	Sp. Gr.	Dense	ity, ρ	α
-	s	${\rm kg/m^3}$	lb_m/ft^3	$^{\circ}\mathrm{C}^{-1}$
Acetone	0.792	792	49.4	0.00149
Benzene	0.879	879	54.9	0.00124
Crude oil, 35°API	0.851	851	53.1	0.00074
Ethanol	0.789	789	49.3	0.00112
Glycerol	$1.26 (50 ^{\circ}\text{C})$	1,260	78.7	_
Kerosene	0.819	819	51.1	0.00093
Mercury	13.55	13,550	845.9	0.000182
Methanol	0.792	792	49.4	0.00120
<i>n</i> -Octane	0.703	703	43.9	_
n-Pentane	0.630	630	39.3	0.00161
Water	0.998	998	62.3	0.000207

Table 1.1 Specific Gravities, Densities, and Thermal Expansion Coefficients of Liquids at 20 °C

Degrees A.P.I. (American Petroleum Institute) are related to specific gravity s by the formula:

$$^{\circ}$$
A.P.I. = $\frac{141.5}{s} - 131.5$. (1.6)

Note that for water, $^{\circ}A.P.I. = 10$, with correspondingly *higher* values for liquids that are *less* dense. Thus, for the crude oil listed in Table 1.1, Eqn. (1.6) indeed gives $141.5/0.851 - 131.5 \doteq 35 ^{\circ}A.P.I.$

Densities of gases. For ideal gases, pV = nRT, where p is the absolute pressure, V is the volume of the gas, n is the number of moles (abbreviated as "mol" when used as a unit), R is the gas constant, and T is the absolute temperature. If $M_{\rm w}$ is the molecular weight of the gas, it follows that:

$$\rho = \frac{nM_{\rm w}}{V} = \frac{M_{\rm w}p}{RT}.\tag{1.7}$$

³ An early appearance of the notation "[=]" is in R.B. Bird, W.E. Stewart, and E.N. Lightfoot, Transport Phenomena, Wiley, New York, 1960.

Thus, the density of an ideal gas depends on the molecular weight, absolute pressure, and absolute temperature. Values of the gas constant R are given in Table 1.2 for various systems of units. Note that degrees Kelvin, formerly represented by " ${}^{\circ}K$," is now more simply denoted as "K."

Value	Units
8.314	J/g-mol K
0.08314	liter bar/g-mol K
0.08206	liter atm/g-mol K
1.987	cal/g-mol K
10.73	psia ft ³ /lb-mol °R
0.7302	ft ³ atm/lb-mol °R
1,545	ft lb _f /lb-mol °R

Table 1.2 Values of the Gas Constant, R

For a nonideal gas, the compressibility factor Z (a function of p and T) is introduced into the denominator of Eqn. (1.7), giving:

$$\rho = \frac{nM_{\rm w}}{V} = \frac{M_{\rm w}p}{ZRT}.\tag{1.8}$$

Thus, the extent to which Z deviates from unity gives a measure of the nonideality of the gas.

The isothermal compressibility of a gas is defined as:

$$\beta = -\frac{1}{V} \left(\frac{\partial V}{\partial p} \right)_T,$$

and equals—at constant temperature—the fractional decrease in volume caused by a unit *increase* in the pressure. For an ideal gas, $\beta = 1/p$, the reciprocal of the absolute pressure.

The coefficient of thermal expansion α of a material is its isobaric (constant pressure) fractional increase in volume per unit rise in temperature:

$$\alpha = \frac{1}{V} \left(\frac{\partial V}{\partial T} \right)_p. \tag{1.9}$$

Since, for a given mass, density is inversely proportional to volume, it follows that for moderate temperature ranges (over which α is essentially constant) the density of most liquids is approximately a linear function of temperature:

$$\rho \doteq \rho_0 [1 - \alpha (T - T_0)], \tag{1.10}$$

where ρ_0 is the density at a reference temperature T_0 . For an ideal gas, $\alpha = 1/T$, the reciprocal of the absolute temperature.

The specific gravity s of a fluid is the ratio of the density ρ to the density ρ_{SC} of a reference fluid at some standard condition:

$$s = \frac{\rho}{\rho_{\rm SC}}.\tag{1.11}$$

For liquids, ρ_{SC} is usually the density of water at 4 °C, which equals 1.000 g/ml or 1,000 kg/m³. For gases, ρ_{SC} is sometimes taken as the density of air at 60 °F and 14.7 psia, which is approximately 0.0759 lb_m/ft³, and sometimes at 0 °C and one atmosphere absolute; since there is no single standard for gases, care must obviously be taken when interpreting published values. For natural gas, consisting primarily of methane and other hydrocarbons, the gas gravity is defined as the ratio of the molecular weight of the gas to that of air (28.8 lb_m/lb-mol).

Values of the molecular weight $M_{\rm w}$ are listed in Table 1.3 for several commonly occurring gases, together with their densities at standard conditions of atmospheric pressure and 0 °C.

Gas	$M_{ m w}$	l Density	
		${\rm kg/m^3}$	lb_m/ft^3
Air	28.8	1.29	0.0802
Carbon dioxide	44.0	1.96	0.1225
Ethylene	28.0	1.25	0.0780
Hydrogen	2.0	0.089	0.0056
Methane	16.0	0.714	0.0446
Nitrogen	28.0	1.25	0.0780
Oxygen	32.0	1.43	0.0891

Table 1.3 Gas Molecular Weights and Densities (the Latter at Atmospheric Pressure and 0°C)

Viscosity. The viscosity of a fluid measures its resistance to flow under an applied shear stress, as shown in Fig. 1.8(a). There, the fluid is ideally supposed to be confined in a relatively small gap of thickness h between one plate that is stationary and another plate that is moving steadily at a velocity V relative to the first plate.

In practice, the situation would essentially be realized by a fluid occupying the space between two concentric cylinders of large radii rotating relative to each other, as in Fig. 1.1. A steady force F to the right is applied to the upper plate (and, to preserve equilibrium, to the left on the lower plate) in order to maintain a

constant motion and to overcome the viscous friction caused by layers of molecules sliding over one another.




Fig. 1.8 (a) Fluid in shear between parallel plates; (b) the ensuing linear velocity profile.

Under these circumstances, the velocity u of the fluid to the right is found experimentally to vary linearly from zero at the lower plate (y = 0) to V itself at the upper plate, as in Fig. 1.8(b), corresponding to no-slip conditions at each plate. At any intermediate distance y from the lower plate, the velocity is simply:

$$u = \frac{y}{h}V. \tag{1.12}$$

Recall that the shear stress τ is the tangential applied force F per unit area:

$$\tau = \frac{F}{A},\tag{1.13}$$

in which A is the area of each plate. Experimentally, for a large class of materials, called Newtonian fluids, the shear stress is directly proportional to the velocity gradient:

$$\tau = \mu \frac{du}{dy} = \mu \frac{V}{h}.\tag{1.14}$$

The proportionality constant μ is called the *viscosity* of the fluid; its dimensions can be found by substituting those for F (ML/T²), A (L²), and du/dy (T⁻¹), giving:

$$\mu [=] \frac{M}{LT}. \tag{1.15}$$

Representative units for viscosity are g/cm s (also known as *poise*, designated by P), kg/m s, and lb_m/ft hr. The *centipoise* (cP), one hundredth of a poise, is also a convenient unit, since the viscosity of water at room temperature is approximately 0.01 P or 1.0 cP. Table 1.11 gives viscosity conversion factors.

The viscosity of a fluid may be determined by observing the pressure drop when it flows at a known rate in a tube, as analyzed in Section 3.2. More sophisticated

methods for determining the *rheological* or flow properties of fluids—including viscosity—are also discussed in Chapter 11; such methods often involve containing the fluid in a small gap between two surfaces, moving one of the surfaces, and measuring the force needed to maintain the other surface stationary.

Liquid	a	b	a	b
-	(T in K)		$(T \text{ in } {}^{\circ}\mathbf{R})$	
Acetone	14.64	-2.77	16.29	-2.77
Benzene	21.99	-3.95	24.34	-3.95
Crude oil, 35° API	53.73	-9.01	59.09	-9.01
Ethanol	31.63	-5.53	34.93	-5.53
Glycerol	106.76	-17.60	117.22	-17.60
Kerosene	33.41	-5.72	36.82	-5.72
Methanol	22.18	-3.99	24.56	-3.99
Octane	17.86	-3.25	19.80	-3.25
Pentane	13.46	-2.62	15.02	-2.62
Water	29.76	-5.24	32.88	-5.24

Table 1.4 Viscosity Parameters for Liquids

The kinematic viscosity ν is the ratio of the viscosity to the density:

$$\nu = \frac{\mu}{\rho},\tag{1.16}$$

and is important in cases in which significant viscous and gravitational forces coexist. The reader can check that the dimensions of ν are L^2/T , which are identical to those for the diffusion coefficient \mathcal{D} in mass transfer and for the thermal diffusivity $\alpha = k/\rho c_p$ in heat transfer. There is a definite analogy among the three quantities—indeed, as seen later, the value of the kinematic viscosity governs the rate of "diffusion" of momentum in the laminar and turbulent flow of fluids.

Viscosities of liquids. The viscosities μ of liquids generally vary approximately with absolute temperature T according to:

$$\ln \mu \doteq a + b \ln T$$
 or $\mu \doteq e^{a+b \ln T}$, (1.17)

and—to a good approximation—are independent of pressure. Assuming that μ is measured in centipoise and that T is either in degrees Kelvin or Rankine, appropriate parameters a and b are given in Table 1.4 for several representative liquids. The resulting values for viscosity are approximate, suitable for a first design only.

Viscosities of gases. The viscosity μ of many gases is approximated by the formula:

$$\mu \doteq \mu_0 \left(\frac{T}{T_0}\right)^n,\tag{1.18}$$

in which T is the absolute temperature (Kelvin or Rankine), μ_0 is the viscosity at an absolute reference temperature T_0 , and n is an empirical exponent that best fits the experimental data. The values of the parameters μ_0 and n for atmospheric pressure are given in Table 1.5; recall that to a *first* approximation, the viscosity of a gas is independent of pressure. The values μ_0 are given in centipoise and correspond to a reference temperature of $T_0 \doteq 273 \text{ K} \doteq 492 \,^{\circ}\text{R}$.

Gas	μ_0 , cP	n
Air	0.0171	0.768
Carbon dioxide	0.0137	0.935
Ethylene	0.0096	0.812
Hydrogen	0.0084	0.695
Methane	0.0120	0.873
Nitrogen	0.0166	0.756
Oxygen	0.0187	0.814

Table 1.5 Viscosity Parameters for Gases

Surface tension.⁴ Surface tension is the tendency of the surface of a liquid to behave like a stretched elastic membrane. There is a natural tendency for liquids to minimize their surface area. The obvious case is that of a liquid droplet on a horizontal surface that is not wetted by the liquid—mercury on glass, or water on a surface that also has a thin oil film on it. For small droplets, such as those on the left of Fig. 1.9, the droplet adopts a shape that is almost perfectly spherical, because in this configuration there is the least surface area for a given volume.



Fig. 1.9 The larger droplets are flatter because gravity is becoming more important than surface tension.

⁴ We recommend that this subsection be omitted at a first reading, because the concept of surface tension is somewhat involved and is relevant only to a small part of this book.

For larger droplets, the shape becomes somewhat flatter because of the increasingly important gravitational effect, which is roughly proportional to a^3 , where a is the approximate droplet radius, whereas the surface area is proportional only to a^2 . Thus, the ratio of gravitational to surface tension effects depends roughly on the value of $a^3/a^2 = a$, and is therefore increasingly important for the larger droplets, as shown to the right in Fig. 1.9. Overall, the situation is very similar to that of a water-filled balloon, in which the water accounts for the gravitational effect and the balloon acts like the surface tension.

A fundamental property is the *surface energy*, which is defined with reference to Fig. 1.10(a). A molecule I, situated in the *interior* of the liquid, is attracted equally in all directions by its neighbors. However, a molecule S, situated in the *surface*, experiences a net attractive force into the bulk of the liquid. (The vapor above the surface, being comparatively rarefied, exerts a negligible force on molecule S.) Therefore, work has to be done against such a force in bringing an interior molecule to the surface. Hence, an energy σ , called the *surface energy*, can be attributed to a unit area of the surface.




Fig. 1.10 (a) Molecules in the interior and surface of a liquid; (b) newly created surface caused by moving the tension T through a distance L.

An equivalent viewpoint is to consider the surface tension T existing per unit distance of a line drawn in the surface, as shown in Fig. 1.10(b). Suppose that such a tension has moved a distance L, thereby creating an area WL of fresh surface. The work done is the product of the force, TW, and the distance L through which it moves, namely TWL, and this must equal the newly acquired surface energy σWL . Therefore, $T = \sigma$; both quantities have units of force per unit distance, such as N/m, which is equivalent to energy per unit area, such as J/m^2 .

We next find the amount p_1-p_2 by which the pressure p_1 inside a liquid droplet of radius r, shown in Fig. 1.11(a), exceeds the pressure p_2 of the surrounding vapor. Fig. 1.11(b) illustrates the equilibrium of the upper hemisphere of the droplet, which is also surrounded by an imaginary cylindrical "control surface" ABCD, on which forces in the vertical direction will soon be equated. Observe that the

internal pressure p_1 is trying to blow apart the two hemispheres (the lower one is not shown), whereas the surface tension σ is trying to pull them together.




Fig. 1.11 Pressure change across a curved surface.

In more detail, there are two different types of forces to be considered:

1. That due to the *pressure difference* between the pressure inside the droplet and the vapor outside, each acting on an area πr^2 (that of the circles CD and AB):

$$(p_1 - p_2)\pi r^2. (1.19)$$

2. That due to surface tension, which acts on the circumference of length $2\pi r$:

$$2\pi r\sigma.$$
 (1.20)

At equilibrium, these two forces are equated, giving:

$$\Delta p = p_1 - p_2 = \frac{2\sigma}{r}.\tag{1.21}$$

That is, there is a *higher* pressure on the concave or droplet side of the interface. What would the pressure change be for a *bubble* instead of a droplet? Why?

More generally, if an interface has principal radii of curvature r_1 and r_2 , the increase in pressure can be shown to be:

$$p_1 - p_2 = \sigma \left(\frac{1}{r_1} + \frac{1}{r_2} \right). \tag{1.22}$$

For a sphere of radius r, as in Fig. 1.11, both radii are equal, so that $r_1 = r_2 = r$, and $p_1 - p_2 = 2\sigma/r$. Problem 1.31 involves a situation in which $r_1 \neq r_2$. The radii r_1 and r_2 will have the same sign if the corresponding centers of curvature are on the same side of the interface; if not, they will be of opposite sign. Appendix A contains further information about the curvature of a surface.




Fig. 1.12 Methods for measuring surface tension.

A brief description of simple experiments for measuring the surface tension σ of a liquid, shown in Fig. 1.12, now follows:

(a) In the capillary-rise method, a narrow tube of internal radius a is dipped vertically into a pool of liquid, which then rises to a height h inside the tube; if the contact angle (the angle between the free surface and the wall) is θ , the meniscus will be approximated by part of the surface of a sphere; from the geometry shown in the enlargement on the right-hand side of Fig. 1.12(a) the radius of the sphere is seen to be $r = a/\cos\theta$. Since the surface is now concave on the air side, the reverse of Eqn. (1.21) occurs, and $p_2 = p_1 - 2\sigma/r$, so that p_2 is below atmospheric pressure p_1 . Now follow the path 1–2–3–4, and observe that $p_4 = p_3$ because points

3 and 4 are at the same elevation in the same liquid. Thus, the pressure at point 4 is:

 $p_4 = p_1 - \frac{2\sigma}{r} + \rho g h.$

However, $p_4 = p_1$ since both of these are at atmospheric pressure. Hence, the surface tension is given by the relation:

$$\sigma = \frac{1}{2}\rho ghr = \frac{\rho gha}{2\cos\theta}.$$
 (1.23)

In many cases—for complete wetting of the surface— θ is essentially zero and $\cos \theta = 1$. However, for liquids such as mercury in glass, there may be a complete *non*-wetting of the surface, in which case $\theta = \pi$, so that $\cos \theta = -1$; the result is that the liquid level in the capillary is then *depressed* below that in the surrounding pool.

(b) In the drop-weight method, a liquid droplet is allowed to form very slowly at the tip of a capillary tube of outer diameter D. The droplet will eventually grow to a size where its weight just overcomes the surface-tension force $\pi D\sigma$ holding it up. At this stage, it will detach from the tube, and its weight w = Mg can be determined by catching it in a small pan and weighing it. By equating the two forces, the surface tension is then calculated from:

$$\sigma = \frac{w}{\pi D}.\tag{1.24}$$

(c) In the *ring tensiometer*, a thin wire ring, suspended from the arm of a sensitive balance, is dipped into the liquid and gently raised, so that it brings a thin liquid film up with it. The force F needed to support the film is measured by the balance. The downward force exerted on a unit length of the ring by one side of the film is the surface tension; since there are two sides to the film, the total force is $2P\sigma$, where P is the circumference of the ring. The surface tension is therefore determined as:

$$\sigma = \frac{F}{2P}.\tag{1.25}$$

In common with most experimental techniques, all three methods described above require slight modifications to the results expressed in Eqns. (1.23)–(1.25) because of imperfections in the simple theories.

Surface tension generally appears only in situations involving either free surfaces (liquid/gas or liquid/solid boundaries) or interfaces (liquid/liquid boundaries); in the latter case, it is usually called the *interfacial* tension.

Representative values for the surface tensions of liquids at 20 °C, in contact either with air or their vapor (there is usually little difference between the two), are given in Table 1.6.⁵

⁵ The values for surface tension have been obtained from the CRC Handbook of Chemistry and Physics, 48th ed., The Chemical Rubber Co., Cleveland, OH, 1967.

Liquid	σ dynes/cm
Acetone	23.70
Benzene	28.85
Ethanol	22.75
Glycerol	63.40
Mercury	435.5
Methanol	22.61
n-Octane	21.80
Water	72.75

Table 1.6 Surface Tensions

1.5 Units and Systems of Units

Mass, weight, and force. The mass M of an object is a measure of the amount of matter it contains and will be constant, since it depends on the number of constituent molecules and their masses. On the other hand, the weight w of the object is the gravitational force on it, and is equal to Mg, where g is the local gravitational acceleration. Mostly, we shall be discussing phenomena occurring at the surface of the earth, where g is approximately 32.174 ft/s² = 9.807 m/s² = 980.7 cm/s². For much of this book, these values are simply taken as 32.2, 9.81, and 981, respectively.

Table 1.7 Representative Units of Force

Newton's second law of motion states that a force F applied to a mass M will give it an acceleration a:

$$F = Ma, (1.26)$$

from which is apparent that force has dimensions ML/T^2 . Table 1.7 gives the corresponding units of force in the SI (meter/kilogram/second), CGS (centimeter/gram/second), and FPS (foot/pound/second) systems.

The poundal is now an archaic unit, hardly ever used. Instead, the *pound force*, lb_f , is much more common in the English system; it is defined as the gravitational force on 1 lb_m , which, if left to fall freely, will do so with an acceleration of 32.2 ft/s^2 . Hence:

$$1 \text{ lb}_{\text{f}} = 32.2 \text{ lb}_{\text{m}} \frac{\text{ft}}{\text{s}^2} = 32.2 \text{ poundals.}$$
 (1.27)

Table 1.8 SI Units

$Physical \ Quantity$	$Name\ of\ Unit$	Symbol for $Unit$	$\begin{array}{c} Definition \\ of \ Unit \end{array}$
Basic Units			
Length	meter	m	_
Mass	kilogram	kg	_
Time	second	\mathbf{s}	_
Temperature	degree		
•	Kelvin	K	_
Supplementary Unit			
Plane angle	radian	rad	
Derived Units			
Acceleration			$\mathrm{m/s^2}$
Angular			1
velocity			$\rm rad/s$
Density			$\mathrm{kg/m^3}$
Energy	joule	J	$kg m^2/s^2$
Force	newton	\mathbf{N}	$kg m/s^2$
Kinematic viscosity			m^2/s
Power	watt	W	$kg m^2/s^3 (J/s)$
Pressure	pascal	Pa	$kg/m s^2 (N/m^2)$
Velocity	Pascar	1 0	m/s
Viscosity			kg/m s

When using lb_f in the ft, lb_m , s (FPS) system, the following conversion factor, commonly called " g_c ," will almost invariably be needed:

$$g_c = 32.2 \frac{lb_m ft/s^2}{lb_f} = 32.2 \frac{lb_m ft}{lb_f s^2}.$$
 (1.28)

Some writers incorporate g_c into their equations, but this approach may be confusing since it virtually implies that one particular set of units is being used, and hence tends to rob the equations of their generality. Why not, for example, also incorporate the conversion factor of $144 \text{ in}^2/\text{ft}^2$ into equations where pressure is expressed in lb_f/in^2 ? We prefer to omit all conversion factors in equations, and introduce them only as needed in evaluating expressions numerically. If the reader is in any doubt, units should *always* be checked when performing calculations.

SI Units. The most systematically developed and universally accepted set of units occurs in the SI units or $Syst\`eme\ International\ d'Unit\'es^6$; the subset we mainly need is shown in Table 1.8.

The basic units are again the meter, kilogram, and second (m, kg, and s); from these, certain *derived* units can also be obtained. Force $(kg m/s^2)$ has already been discussed; energy is the product of force and length; power amounts to energy per unit time; surface tension is energy per unit area or force per unit length, and so on. Some of the units have names, and these, together with their abbreviations, are also given in Table 1.8.

Physical Quantity	$Name\ of\ Unit$	Symbol for $Unit$	$\begin{array}{c} Definition \\ of \ Unit \end{array}$
Area	hectare	ha	10^4 m^2
Kinematic viscosity	stokes	St	$10^{-4} \text{ m}^2/\text{s}$
Length	micron	$\mu\mathrm{m}$	10^{-6} m
Mass	tonne	t	$10^3 \text{ kg} = \text{Mg}$
	gram	g	$10^{-3} \text{ kg} = \text{g}$
Pressure	bar	bar	$10^5 \ { m N/m^2}$
Viscosity	poise	P	10^{-1} kg/m s
Volume	liter	1	10^{-3} m^{3}

Table 1.9 Auxiliary Units Allowed in Conjunction with SI Units

Tradition dies hard, and certain other "metric" units are so well established that they may be used as *auxiliary* units; these are shown in Table 1.9. The *gram* is the classic example. Note that the basic SI unit of mass (kg) is even represented in terms of the gram, and has not yet been given a name of its own!

Table 1.10 shows some of the acceptable prefixes that can be used for accommodating both small and large quantities. For example, to avoid an excessive number of decimal places, 0.000001 s is normally better expressed as 1 μ s (one microsecond). Note also, for example, that 1 μ kg should be written as 1 mg—one prefix being better than two.

⁶ For an excellent discussion, on which Tables 1.8 and 1.9 are based, see Metrication in Scientific Journals, published by The Royal Society, London, 1968.

Factor	Name	Symbol	Factor	Name	Symbol
$10^{-12} 10^{-9} 10^{-6} 10^{-3}$	pico nano micro milli	$egin{array}{c} \mathbf{p} \\ \mathbf{n} \\ \mu \\ \mathbf{m} \end{array}$	$ \begin{array}{c} 10^3 \\ 10^6 \\ 10^9 \\ 10^{12} \end{array} $	kilo mega giga tera	k M G T

Table 1.10 Prefixes for Fractions and Multiples

Some of the more frequently used conversion factors are given in Table 1.11.

Example 1.1—Units Conversion

Part 1. Express 65 mph in (a) ft/s, and (b) m/s.

Solution

The solution is obtained by employing conversion factors taken from Table 1.11:

(a)
$$65 \frac{\text{mile}}{\text{hr}} \times \frac{1}{3.600} \frac{\text{hr}}{\text{s}} \times 5,280 \frac{\text{ft}}{\text{mile}} = 95.33 \frac{\text{ft}}{\text{s}}.$$

(b)
$$95.33 \frac{\text{ft}}{\text{s}} \times 0.3048 \frac{\text{m}}{\text{ft}} = 29.06 \frac{\text{m}}{\text{s}}$$
.

Part~2. The density of 35 °API crude oil is 53.1 lb_m/ft^3 at 68 °F and its viscosity is 32.8 lb_m/ft hr. What are its density, viscosity, and kinematic viscosity in SI units?

Solution

$$\begin{array}{lllll} \rho = & 53.1 \; \frac{lb_m}{ft^3} \; \times \; 0.4536 \; \frac{kg}{lb_m} \; \times \; \frac{1}{0.3048^3} \; \frac{ft^3}{m^3} \; = \; 851 \; \frac{kg}{m^3} \, . \\ \\ \mu = & 32.8 \; \frac{lb_m}{ft \; hr} \; \times \; \frac{1}{2.419} \; \frac{centipoise}{lb_m/ft \; hr} \; \times \; 0.01 \; \frac{poise}{centipoise} \; = 0.136 \; poise. \end{array}$$

Or, converting to SI units, noting that P is the symbol for poise, and evaluating ν :

$$\mu = 0.136 \text{ P} \times 0.1 \frac{\text{kg/m s}}{\text{P}} = 0.0136 \frac{\text{kg}}{\text{m s}}.$$

$$\nu = \frac{\mu}{\rho} = \frac{0.0136 \text{ kg/m s}}{851 \text{ kg/m}^3} = 1.60 \times 10^{-5} \frac{\text{m}^2}{\text{s}} \quad (= 0.160 \text{ St}).$$

Table 1.11 Commonly Used Conversion Factors

Area	1 mile^2	=	640 acres
	1 acre	=	0.4047 ha
Energy	1 BTU	=	1,055 J
	1 cal	=	4.184 J
	1 J	=	$0.7376 \text{ ft lb}_{\mathrm{f}}$
	1 erg	=	1 dyne cm
Force	1 lb_{f}	=	4.448 N
	1 N	=	$0.2248~\mathrm{lb_f}$
Length	1 ft	=	$0.3048 \mathrm{\ m}$
	1 m	=	$3.281 \mathrm{ft}$
	1 mile	=	5,280 ft
Mass	1 lb_{m}	=	0.4536 kg
	1 kg	=	$2.205~\mathrm{lb_m}$
Power	1 HP	=	$550 \text{ ft } \text{lb}_{\text{f}}/\text{s}$
	1 kW	=	$737.6 ext{ ft } ext{lb}_{ ext{f}}/ ext{s}$
Pressure	1 atm	=	$14.696 \; lb_f/in^2$
	1 atm	=	$1.0133 \mathrm{bar}$
	$1 \mathrm{\ atm}$	=	$1.0133 \times 10^5 \text{ Pa}$
Time	1 day	=	24 hr
	1 hr	=	$60 \min$
	$1 \min$	=	60 s
Viscosity	1 cP	=	$2.419 \; \mathrm{lb_m/ft \; hr}$
	1 cP	=	0.001 kg/m s
	1 cP	=	$0.000672~\mathrm{lb_m/ft~s}$
	$1 \text{ lb}_{\text{f}} \text{ s/ft}^2$	=	$4.788 \times 10^{4} \text{ cP}$
Volume	$1 { m ft}^3$	=	7.481 U.S. gal
	1 U.S. gal	=	3.785 1
	$1 \mathrm{\ m^3}$	=	264.2 U.S. gal

Example 1.2—Mass of Air in a Room

Estimate the mass of air in your classroom, which is 80 ft wide, 40 ft deep, and 12 ft high. The gas constant is R=10.73 psia ft³/lb-mol °R.

Solution

The volume of the classroom, shown in Fig. E1.2, is:

$$V = 80 \times 40 \times 12 = 3.84 \times 10^4 \text{ ft}^3.$$




Fig. E1.2 Assumed dimensions of classroom.

If the air is approximately 20% oxygen and 80% nitrogen, its mean molecular weight is $M_{\rm w}=0.8\times28+0.2\times32=28.8~{\rm lb_m/lb\text{-}mol}$. From the gas law, assuming an absolute pressure of p=14.7 psia and a temperature of $70\,{\rm ^\circ F}=530\,{\rm ^\circ R}$, the density is:

$$\rho = \frac{M_{\rm w}p}{RT} = \frac{28.8 \; ({\rm lb_m/lb \; mol}) \times 14.7 \; ({\rm psia})}{10.73 \; ({\rm psia \; ft^3/lb \; mol} \; ^{\circ}{\rm R}) \times 530 \; (^{\circ}{\rm R})} = 0.0744 \; {\rm lb_m/ft^3}.$$

Hence, the mass of air is:

$$M = \rho V = 0.0744 \text{ (lb}_{m}/\text{ft}^{3}) \times 3.84 \times 10^{4} \text{ (ft}^{3}) = 2,860 \text{ lb}_{m}.$$

For the rest of the book, manipulation of units will often be less detailed; the reader should always check if there is any doubt.

1.6 Hydrostatics

Variation of pressure with elevation. Here, we investigate how the pressure in a stationary fluid varies with elevation z. The result is useful because it can answer questions such as "What is the pressure at the summit of Mt. Annapurna?" or "What forces are exerted on the walls of an oil storage tank?" Consider a hypothetical differential cylindrical element of fluid of cross-sectional area A, height dz, and volume $A\,dz$, which is also surrounded by the same fluid, as shown in Fig. 1.13. Its weight, being the downwards gravitational force on its mass, is $dW = \rho A\,dz\,g$. Two completely equivalent approaches will be presented:

Method 1. Let p denote the pressure at the base of the cylinder; since p changes at a rate dp/dz with elevation, the pressure is found either from Taylor's expansion or the definition of a derivative to be p + (dp/dz)dz at the top of the cylinder. (Note that we do not anticipate a reduction of pressure with elevation here; hence, the plus sign is used. If, indeed—as proves to be the case—pressure falls with increasing elevation, then the subsequent development will tell us that

Further details of this fundamental statement can be found in Appendix A and must be fully understood, because similar assertions appear repeatedly throughout the book.

dp/dz is negative.) Hence, the fluid exerts an *upward* force of pA on the base of the cylinder, and a *downward* force of [p + (dp/dz)dz]A on the top of the cylinder.

Next, apply Newton's second law of motion by equating the net upward force to the mass times the acceleration—which is zero, since the cylinder is stationary:

$$\underbrace{pA - \left(p + \frac{dp}{dz}dz\right)A}_{\text{Net pressure force}} - \underbrace{\rho A \, dz \, g}_{\text{Weight}} = \underbrace{\left(\rho A \, dz\right)}_{\text{Mass}} \times 0 = 0. \tag{1.29}$$

Cancellation of pA and division by A dz leads to the following differential equation, which governs the rate of change of pressure with elevation:

$$\frac{dp}{dz} = -\rho g. ag{1.30}$$




Fig. 1.13 Forces acting on a cylinder of fluid.

Method 2. Let p_z and p_{z+dz} denote the pressures at the base and top of the cylinder, where the elevations are z and z+dz, respectively. Hence, the fluid exerts an upward force of $p_z A$ on the base of the cylinder, and a downward force of $p_{z+dz} A$ on the top of the cylinder. Application of Newton's second law of motion gives:

$$\underbrace{p_z A - p_{z+dz} A}_{\text{Net pressure force}} - \underbrace{\rho A \, dz \, g}_{\text{Weight}} = \underbrace{(\rho A \, dz)}_{\text{Mass}} \times 0 = 0. \tag{1.31}$$

Isolation of the two pressure terms on the left-hand side and division by A dz gives:

$$\frac{p_{z+dz} - p_z}{dz} = -\rho g. ag{1.32}$$

As dz tends to zero, the left-hand side of Eqn. (1.32) becomes the derivative dp/dz, leading to the same result as previously:

$$\frac{dp}{dz} = -\rho g. \tag{1.30}$$

The same conclusion can also be obtained by considering a cylinder of *finite* height Δz and then letting Δz approach zero.

Note that Eqn. (1.30) predicts a pressure decrease in the vertically upward direction at a rate that is proportional to the local density. Such pressure variations can readily be detected by the ear when traveling quickly in an elevator in a tall building, or when taking off in an airplane. The reader must thoroughly understand both the above approaches. For most of this book, we shall use Method 1, because it eliminates the steps of taking the limit of $dz \to 0$ and invoking the definition of the derivative.

Pressure in a liquid with a free surface. In Fig. 1.14, the pressure is p_s at the free surface, and we wish to find the pressure p at a depth H below the free surface—of water in a swimming pool, for example.




Fig. 1.14 Pressure at a depth H.

Separation of variables in Eqn. (1.30) and integration between the free surface (z = H) and a depth H (z = 0) gives:

$$\int_{p_0}^{p} dp = -\int_{H}^{0} \rho g \, dz. \tag{1.33}$$

Assuming—quite reasonably—that ρ and g are constants in the liquid, these quantities may be taken outside the integral, yielding:

$$p = p_s + \rho g H, \tag{1.34}$$

which predicts a *linear* increase of pressure with distance downward from the free surface. For large depths, such as those encountered by deep-sea divers, very substantial pressures will result.



Example 1.3—Pressure in an Oil Storage Tank

What is the absolute pressure at the bottom of the cylindrical tank of Fig. E1.3, filled to a depth of H with crude oil, with its free surface exposed to the atmosphere? The specific gravity of the crude oil is 0.846. Give the answers for (a) H = 15.0 ft (pressure in lb_f/in^2), and (b) H = 5.0 m (pressure in Pa and bar). What is the purpose of the surrounding dike?




Fig. E1.3 Crude oil storage tank.

Solution

(a) The pressure is that of the atmosphere, p_a , plus the increase due to a column of depth H = 15.0 ft. Thus, setting $p_s = p_a$, Eqn. (1.34) gives:

$$p = p_a + \rho g H$$
= 14.7 + $\frac{0.846 \times 62.3 \times 32.2 \times 15.0}{144 \times 32.2}$
= 14.7 + 5.49 = 20.2 psia.

The reader should check the units, noting that the 32.2 in the numerator is $g = [f/s^2]$, and that the 32.2 in the denominator is $g = [f/s^2]$ in the denominator is $g = [f/s^2]$.

(b) For SI units, no conversion factors are needed. Noting that the density of water is 1,000 kg/m³, and that $p_a \doteq 1.01 \times 10^5$ Pa absolute:

$$p = 1.01 \times 10^5 \, + \, 0.846 \, \times \, 1{,}000 \, \times \, 9.81 \, \times \, 5.0 = 1.42 \, \times \, 10^5 \, \, \mathrm{Pa} = 1.42 \, \, \mathrm{bar}.$$

In the event of a tank rupture, the dike contains the leaking oil and facilitates prevention of spreading fire and contamination of the environment.

Epilogue

When he arrived at work in an oil refinery one morning, the author saw first-hand the consequences of an inadequately vented oil-storage tank. Rain during the night had caused partial condensation of vapor inside the tank, whose pressure had become sufficiently lowered so that the external atmospheric pressure had crumpled the steel tank just as if it were a flimsy tin can. The refinery manager was not pleased.

Example 1.4—Multiple Fluid Hydrostatics

The U-tube shown in Fig. E1.4 contains oil and water columns, between which there is a long trapped air bubble. For the indicated heights of the columns, find the specific gravity of the oil.




Fig. E1.4 Oil/air/water system.

Solution

The pressure p_2 at point 2 may be deduced by starting with the pressure p_1 at point 1 and adding or subtracting, as appropriate, the hydrostatic pressure changes due to the various columns of fluid. Note that the width of the U-tube (2.0 ft) is irrelevant, since there is no change in pressure in the horizontal leg. We obtain:

$$p_2 = p_1 + \rho_o g h_1 + \rho_a g h_2 + \rho_w g h_3 - \rho_w g h_4,$$
 (E1.4.1)

in which ρ_o , ρ_a , and ρ_w denote the densities of oil, air, and water, respectively. Since the density of the air is very small compared to that of oil or water, the term containing ρ_a can be neglected. Also, $p_1 = p_2$, because both are equal to atmospheric pressure. Equation (E1.4.1) can then be solved for the specific gravity s_o of the oil:

$$s_o = \frac{\rho_o}{\rho_w} = \frac{h_4 - h_3}{h_1} = \frac{3.0 - 1.0}{2.5} = 0.80.$$

Pressure variations in a gas. For a gas, the density is no longer constant, but is a function of pressure (and of temperature—although temperature variations are usually less significant than those of pressure), and there are two approaches:

- 1. For *small* changes in elevation, the assumption of constant density can still be made, and equations similar to Eqn. (1.34) are still approximately valid.
- 2. For moderate or large changes in elevation, the density in Eqn. (1.30) is given by Eqn. (1.7) or (1.8), $\rho = M_{\rm w} p/RT$ or $\rho = M_{\rm w} p/ZRT$, depending on whether

the gas is ideal or nonideal. It is understood that absolute pressure and temperature must always be used whenever the gas law is involved. A separation of variables can still be made, followed by integration, but the result will now be more complicated because the term dp/p occurs, leading—at the simplest (for an isothermal situation)—to a decreasing exponential variation of pressure with elevation.

Example 1.5—Pressure Variations in a Gas

For a gas of molecular weight $M_{\rm w}$ (such as the earth's atmosphere), investigate how the pressure p varies with elevation z if $p=p_0$ at z=0. Assume that the temperature T is constant. What approximation may be made for *small* elevation increases? Explain how you would proceed for the nonisothermal case, in which T=T(z) is a known function of elevation.

Solution

Assuming ideal gas behavior, Eqns. (1.30) and (1.7) give:

$$\frac{dp}{dz} = -\rho g = -\frac{M_{\rm w}p}{RT}g. \tag{E1.5.1}$$

Separation of variables and integration between appropriate limits yields:

$$\int_{p_0}^{p} \frac{dp}{p} = \ln \frac{p}{p_0} = -\int_0^z \frac{M_{\rm w}g}{RT} dz = -\frac{M_{\rm w}g}{RT} \int_0^z dz = -\frac{M_{\rm w}gz}{RT},$$
 (E1.5.2)

since $M_{\rm w}g/RT$ is constant. Hence, there is an exponential decrease of pressure with elevation, as shown in Fig. E1.5:

$$p = p_0 \exp\left(-\frac{M_{\rm w}g}{RT}z\right). \tag{E1.5.3}$$

Since a Taylor's expansion gives $e^{-x} = 1 - x + x^2/2 - \dots$, the pressure is approximated by:

$$p \doteq p_0 \left[1 - \frac{M_{\rm w}g}{RT} z + \left(\frac{M_{\rm w}g}{RT} \right)^2 \frac{z^2}{2} \right].$$
 (E1.5.4)

For small values of $M_{\rm w}gz/RT$, the last term is an insignificant second-order effect (compressibility effects are unimportant), and we obtain:

$$p \doteq p_0 - \frac{M_{\rm w} p_0}{RT} gz = p_0 - \rho_0 gz,$$
 (E1.5.5)

in which ρ_0 is the density at elevation z=0; this approximation—essentially one of constant density—is shown as the dashed line in Fig. E1.5 and is clearly

applicable only for a small change of elevation. Problem 1.19 investigates the upper limit on z for which this linear approximation is realistic. If there are significant elevation changes—as in Problems 1.16 and 1.30—the approximation of Eqn. (E1.5.5) cannot be used with any accuracy. Observe with caution that the Taylor's expansion is only a vehicle for demonstrating what happens for small values of $M_{\rm w}gz/RT$. Actual calculations for larger values of $M_{\rm w}gz/RT$ should be made using Eqn. (E1.5.3), not Eqn. (E1.5.4).




Fig. E1.5 Variation of gas pressure with elevation.

For the case in which the temperature is not constant, but is a known function T(z) of elevation (as might be deduced from observations made by a meteorological balloon), it must be included *inside* the integral:

$$\int_{p_1}^{p_2} \frac{dp}{p} = -\frac{M_{\rm w}g}{R} \int_0^z \frac{dz}{T(z)}.$$
 (E1.5.6)

Since T(z) is unlikely to be a simple function of z, a numerical method—such as Simpson's rule in Appendix A—will probably have to be used to approximate the second integral of Eqn. (E1.5.6).

Total force on a dam or lock gate. Fig. 1.15 shows the side and end elevations of a dam or lock gate of depth D and width W. An expression is needed for the total horizontal force F exerted by the liquid on the dam, so that the latter can be made of appropriate strength. Similar results would apply for liquids in storage tanks. Gauge pressures are used for simplicity, with p=0 at the free surface and in the air outside the dam. Absolute pressures could also be employed, but would merely add a constant atmospheric pressure everywhere, and would eventually be canceled out. If the coordinate z is measured from the bottom of the liquid upward, the corresponding depth of a point below the free surface is D-z. Hence, from Eqn. (1.34), the differential horizontal force dF on an infinitesimally small rectangular strip of area dA = Wdz is:

$$dF = pWdz = \rho g(D - z)Wdz. \tag{1.35}$$




Fig. 1.15 Horizontal thrust on a dam: (a) side elevation, (b) end elevation.

Integration from the bottom (z = 0) to the top (z = D) of the dam gives the total horizontal force:

$$F = \int_0^F dF = \int_0^D \rho g W(D - z) \, dz = \frac{1}{2} \rho g W D^2. \tag{1.36}$$

Horizontal pressure force on an arbitrary plane vertical surface. The preceding analysis was for a regular shape. A more general case is illustrated in Fig. 1.16, which shows a *plane* vertical surface of *arbitrary* shape. Note that it is now slightly easier to work in terms of a *downward* coordinate h.




Fig. 1.16 Side view of a pool of liquid with a submerged vertical surface.

Again taking gauge pressures for simplicity (the gas law is not involved), with p = 0 at the free surface, the total horizontal force is:

$$F = \int_{A} p \, dA = \int_{A} \rho g h \, dA = \rho g A \frac{\int_{A} h \, dA}{A}. \tag{1.37}$$

But the depth h_c of the centroid of the surface is defined as:

$$h_c \equiv \frac{\int_A h \, dA}{A}.\tag{1.38}$$

Thus, from Eqns. (1.37) and (1.38), the total force is:

$$F = \rho g h_c A = p_c A, \tag{1.39}$$

in which p_c is the pressure at the centroid.

The advantage of this approach is that the location of the centroid is already known for several geometries. For example, for a rectangle of depth D and width W:

$$h_c = \frac{1}{2}D$$
 and $F = \frac{1}{2}\rho gWD^2$, (1.40)

in agreement with the earlier result of Eqn. (1.36). Similarly, for a vertical circle that is just submerged, the depth of the centroid equals its radius. And, for a vertical triangle with one edge coincident with the surface of the liquid, the depth of the centroid equals one-third of its altitude.




Fig. 1.17 Thrust on surface of uniform cross-sectional shape.

Horizontal pressure force on a curved surface. Fig. 1.17(a) shows the cross section of a submerged surface that is no longer plane. However, the shape is uniform normal to the plane of the diagram.

In general, as shown in Fig. 1.17(b), the local pressure force $p\,dA$ on an element of surface area dA does not act horizontally; therefore, its horizontal component must be obtained by projection through an angle of $(\pi/2 - \theta)$, by multiplying by $\cos(\pi/2 - \theta) = \sin\theta$. The total horizontal force F is then:

$$F = \int_{A} p \sin \theta \, dA = \int_{A^*} p \, dA^*, \tag{1.41}$$

in which $dA^* = dA \sin \theta$ is an element of the projection of A onto the hypothetical vertical plane A*. The integral of Eqn. (1.41) can be obtained readily, as illustrated in the following example.

Example 1.6—Hydrostatic Force on a Curved Surface

A submarine, whose hull has a circular cross section of diameter D, is just submerged in water of density ρ , as shown in Fig. E1.6. Derive an equation that gives the total horizontal force F_x on the left half of the hull, for a distance W normal to the plane of the diagram. If D=8 m, the circular cross section continues essentially for the total length W=50 m of the submarine, and the density of sea water is $\rho=1,026$ kg/m³, determine the total horizontal force on the left-hand half of the hull.

Solution

The force is obtained by evaluating the integral of Eqn. (1.41), which is identical to that for the rectangle in Fig. 1.15:

$$F_x = \int_{A^*} p \, dA = \int_{z=0}^{z=D} \rho g W(D-z) \, dz = \frac{1}{2} \, \rho g W D^2.$$
 (E1.6.1)

Insertion of the numerical values gives:

$$F_x = \frac{1}{2} \times 1,026 \times 9.81 \times 50 \times 8.0^2 = 1.61 \times 10^7 \text{ N.}$$
 (E1.6.2)




Fig. E1.6 Submarine just submerged in seawater.

Thus, the total force is considerable—about $3.62 \times 10^6 \ \mathrm{lb_f}$.



Archimedes, ca. 287–212 B.C. Archimedes was a Greek mathematician and inventor. He was born in Syracuse, Italy, where he spent much of his life, apart from a period of study in Alexandria. He was much more interested in mathematical research than any of the ingenious inventions that made him famous. One invention was a "burning mirror," which focused the sun's rays to cause intense heat. Another was the rotating Archimedean screw, for raising a continuous stream of water. Presented with a crown supposedly of pure gold, Archimedes tested the possibility that it might be "diluted" by silver by separately immersing the crown and an equal weight of pure gold into his bath, and observed the difference in the overflow. Legend has it that he was so excited by the result that he ran home without his clothes, shouting " $\epsilon v \rho \eta \kappa \alpha$, $\epsilon v \rho \eta \kappa \alpha$ ", "I have found it, I have found it." To dramatize the effect of a lever, he said, "Give me a place to stand, and I will move the earth." He considered his most important intellectual contribution to be the determination of the ratio of the volume of a sphere to the volume of the cylinder that circumscribes it. [Now that calculus has been invented, the reader might like to derive this ratio! Sadly, Archimedes was killed during the capture of Syracuse by the Romans.

Source: $The\ Encyclopædia\ Britannica,\ 11$ th ed., Cambridge University Press (1910–1911).

Buoyancy forces. If an object is submerged in a fluid, it will experience a net upward or buoyant force exerted by the fluid. To find this force, first examine the buoyant force on a submerged circular cylinder of height H and cross-sectional area A, shown in Fig. 1.18.




Fig. 1.18 Pressure forces on a submerged cylinder.

The forces on the curved vertical surface act horizontally and may therefore be ignored. Hence, the net *upward* force due to the difference between the opposing pressures on the bottom and top faces is:

$$F = (p + \rho gH - p)A = \rho HAg, \qquad (1.42)$$

which is exactly the weight of the displaced liquid, thus verifying *Archimedes' law*, (the buoyant force equals the weight of the fluid displaced) for the cylinder. The same result would clearly be obtained for a cylinder of any uniform cross section.




Fig. 1.19 Buoyancy force for an arbitrary shape.

Fig. 1.19 shows a more general situation, with a body of arbitrary shape. However, Archimedes' law still holds since the body can be decomposed into an infinitely large number of vertical rectangular parallelepipeds or "boxes" of infinitesimally small cross-sectional area dA. The effect for one box is then summed or "integrated" over all the boxes, and again gives the net upward buoyant force as the weight of the liquid displaced.

Example 1.7—Application of Archimedes' Law

Consider the situation in Fig. E1.7(a), in which a barrel rests on a raft that floats in a swimming pool. The barrel is then pushed off the raft, and may either float or sink, depending on its contents and hence its mass. The cross-hatching shows the volumes of water that are displaced. For each of the cases shown in Fig. E1.7 (b) and (c), determine whether the water level in the pool will rise, fall, or remain constant, relative to the initial level in (a).




Fig. E1.7 Raft and barrel in swimming pool: (a) initial positions, (b) light barrel rolls off and floats, (c) heavy barrel rolls off and sinks. The cross-hatching shows volumes below the surface of the water.

Solution

Initial state. Let the masses of the raft and barrel be M_r and M_b , respectively. If the volume of displaced water is initially V in (a), Archimedes' law requires that the total weight of the raft and barrel equals the weight of the displaced water, whose density is ρ :

$$(M_r + M_b)g = V\rho g. (E1.7.1)$$

Barrel floats. If the barrel floats, as in (b), with submerged volumes of V_r and V_b for the raft and barrel, respectively, Archimedes' law may be applied to the raft and barrel separately:

Raft:
$$M_r g = V_r \rho g$$
, Barrel: $M_b g = V_b \rho g$. (E1.7.2)

Addition of the two equations (E1.7.2) and comparison with Eqn. (E1.7.1) shows that:

$$V_r + V_b = V. (E1.7.3)$$

Therefore, since the volume of the water is constant, and the total displaced volume does not change, the level of the surface also remains *unchanged*.

Barrel sinks. Archimedes' law may still be applied to the raft, but the weight of the water displaced by the barrel no longer suffices to support the weight of the barrel, so that:

Raft:
$$M_r g = V_r \rho g$$
, Barrel: $M_b g > V_b \rho g$. (E1.7.4)

Addition of the two relations in (E1.7.4) and comparison with Eqn. (E1.7.1) shows that:

$$V_r + V_b < V. (E1.7.5)$$

Therefore, since the volume of the water in the pool is constant, and the total displaced volume is reduced, the level of the surface falls. This result is perhaps contrary to intuition: since the whole volume of the barrel is submerged in (c), it might be thought that the water level will rise above that in (b). However, because the barrel must be heavy in order to sink, the load on the raft and hence V_r are substantially reduced, so that the total displaced volume is also reduced.

This problem illustrates the need for a complete analysis rather than jumping to a possibly erroneous conclusion. \Box



1.7 Pressure Change Caused by Rotation

Finally, consider the shape of the free surface for the situation shown in Fig. 1.20(a), in which a cylindrical container, partly filled with liquid, is rotated with an angular velocity ω —that is, at $N = \omega/2\pi$ revolutions per unit time. The analysis has applications in fuel tanks of spinning rockets, centrifugal filters, and liquid mirrors.




Fig. 1.20 Pressure changes for rotating cylinder: (a) elevation, (b) plan.

Point O denotes the origin, where r=0 and z=0. After a sufficiently long time, the rotation of the container will be transmitted by viscous action to the liquid, whose rotation is called a *forced vortex*. In fact, the liquid spins as if it were a *solid body*, rotating with a uniform angular velocity ω , so that the velocity in the direction of rotation at a radial location r is given by $v_{\theta} = r\omega$. It is therefore appropriate to treat the situation similar to the hydrostatic investigations already made.

Suppose that the liquid element P is essentially a rectangular box with cross-sectional area dA and radial extent dr. (In reality, the element has slightly tapering sides, but a more elaborate treatment taking this into account will yield identical results to those derived here.) The pressure on the inner face is p, whereas that on the outer face is $p + (\partial p/\partial r)dr$. Also, for uniform rotation in a circular path of radius r, the acceleration toward the center O of the circle is $r\omega^2$. Newton's second law of motion is then used for equating the net pressure force toward O to the mass of the element times its acceleration:

$$\underbrace{\left(p + \frac{\partial p}{\partial r}dr - p\right)dA}_{\text{Net pressure force}} = \underbrace{\rho(dA\,dr)}_{\text{Mass}}r\omega^{2}.$$
(1.43)

40

Note that the use of a *partial* derivative is essential, since the pressure now varies in both the horizontal (radial) and vertical directions. Simplification yields the variation of pressure in the radial direction:

$$\frac{\partial p}{\partial r} = \rho r \omega^2,\tag{1.44}$$

so that pressure *increases* in the radially outward direction.

Observe that the gauge pressure at all points on the interface is zero; in particular, $p_{\rm O} = p_{\rm Q} = 0$. Integrating from points O to P (at constant z):

$$\int_{p=0}^{p_{\rm P}} dp = \rho \omega^2 \int_0^r r \, dr,$$

$$p_{\rm P} = \frac{1}{2} \rho \omega^2 r^2. \tag{1.45}$$

However, the pressure at P can also be obtained by considering the usual hydrostatic increase in traversing the path QP:

$$p_{\rm P} = \rho g z. \tag{1.46}$$

Elimination of the intermediate pressure $p_{\rm P}$ between Eqns. (1.45) and (1.46) relates the elevation of the free surface to the radial location:

$$z = \frac{\omega^2 r^2}{2g}. ag{1.47}$$

Thus, the free surface is *parabolic* in shape; observe also that the density is not a factor, having been canceled from the equations.

There is another type of vortex—the *free* vortex—that is also important, in cyclone dust collectors and tornadoes, for example, as discussed in Chapters 4 and 7. There, the velocity in the angular direction is given by $v_{\theta} = c/r$, where c is a constant, so that v_{θ} is inversely proportional to the radial position.

Example 1.8—Overflow from a Spinning Container

A cylindrical container of height H and radius a is initially half-filled with a liquid. The cylinder is then spun steadily around its vertical axis Z-Z, as shown in Fig. E1.8. At what value of the angular velocity ω will the liquid just start to spill over the top of the container? If H=1 ft and a=0.25 ft, how many rpm (revolutions per minute) would be needed?




Fig. E1.8 Geometry of a spinning container: (a) at rest, (b) on the point of overflowing.

Solution

From Eqn. (1.47), the shape of the free surface is a parabola. Therefore, the air inside the rotating cylinder forms a paraboloid of revolution, whose volume is known from calculus to be exactly one-half of the volume of the "circumscribing cylinder," namely, the container.⁸ Hence, the liquid at the center reaches the bottom of the cylinder *just* as the liquid at the curved wall reaches the top of the cylinder. In Eqn. (1.47), therefore, set z = H and r = a, giving the required angular velocity:

$$\omega = \sqrt{\frac{2gH}{a^2}}.$$

For the stated values:

$$\omega = \sqrt{\frac{2 \times 32.2 \times 1}{0.25^2}} = 32.1 \frac{\text{rad}}{\text{s}}, \qquad N = \frac{\omega}{2\pi} = \frac{32.1 \times 60}{2\pi} = 306.5 \text{ rpm.} \quad \Box$$

$$z = H \frac{r^2}{a^2}.$$

The volume of the paraboloid of air within the cylinder is therefore:

$$V = \int_{z=0}^{z=H} \pi r^2 dz = \int_{z=0}^{z=H} \frac{\pi a^2 z}{H} dz = \frac{1}{2} \pi a^2 H,$$

which is exactly one-half of the volume of the cylinder, $\pi a^2 H$. Since the container was initially just half filled, the liquid volume still accounts for the remaining half.

 $^{^8}$ Proof can be accomplished as follows. First, note for the parabolic surface in Fig. E1.8(b), r=a when z=H, so, from Eqn. (1.47), $\omega^2/2g=H/a^2.$ Thus, Eqn. (1.47) can be rewritten as:

PROBLEMS FOR CHAPTER 1

- 1. Units conversion—E. How many cubic feet are there in an acre-foot? How many gallons? How many cubic meters? How many tonnes of water?
- **2.** Units conversion—E. The viscosity μ of an oil is 10 cP and its specific gravity s is 0.8. Reexpress both of these (the latter as density ρ) in both the lb_m, ft, s system and in SI units.
- 3. Units conversion—E. Use conversion factors to express: (a) the gravitational acceleration of 32.174 ft/s^2 in SI units, and (b) a pressure of $14.7 \text{ lb}_f/\text{in}^2$ (one atmosphere) in both pascals and bars.
- 4. Meteorite density—E. The Barringer Crater in Arizona was formed 30,000 years ago by a spherical meteorite of diameter 60 m and mass 10⁶ t (tonnes), traveling at 15 km/s when it hit the ground.⁹ (Clearly, all figures are estimates.) What was the mean density of the meteorite? What was the predominant material in the meteorite? Why? If one tonne of the explosive TNT is equivalent to five billion joules, how many tonnes of TNT would have had the same impact as the meteorite?
- 5. Reynolds number—E. What is the mean velocity u_m (ft/s) and the Reynolds number Re = $\rho u_m D/\mu$ for 35 gpm (gallons per minute) of water flowing in a 1.05-in. I.D. pipe if its density is $\rho = 62.3$ lb_m/ft³ and its viscosity is $\mu = 1.2$ cP? What are the units of the Reynolds number?
- **6.** Pressure in bubble—E. Consider a soap-film bubble of diameter d. If the external air pressure is p_a , and the surface tension of the soap film is σ , derive an expression for the pressure p_b inside the bubble. Hint: Note that there are two air/liquid interfaces.




Fig. P1.7 Waterflooding of an oil reservoir.

⁹ Richard A.F. Grieve, "Impact cratering on the earth," Scientific American, Vol. 262, No. 4, p. 68 (1990).

7. Reservoir waterflooding—E. Fig. P1.7(a) shows how water is pumped down one well, of depth H, into an oil-bearing stratum, so that the displaced oil then flows up through another well. Fig. P1.7(b) shows an enlargement of an idealized pore, of diameter d, at the water/oil interface.

If the water and oil are just starting to move, what water inlet pressure p_w is needed if the oil exit pressure is to be p_o ? Assume that the oil completely wets the pore (not always the case), that the water/oil interfacial tension is σ , and that the densities of the water and oil are ρ_w and ρ_o , respectively.¹⁰

8. Barometer reading—M. In your house (elevation 950 ft above sea level) you have a barometer that registers inches of mercury. On an average day in January, you telephone the weather station (elevation 700 ft) and are told that the exact pressure there is 0.966 bar. What is the correct reading for your barometer, and to how many psia does this correspond? The specific gravity of mercury is 13.57.




Fig. P1.9 Cylinder immersed in water and liquid A.

9. Two-layer buoyancy—E. As shown in Fig. P1.9, a layer of an unknown liquid A (immiscible with water) floats on top of a layer of water W in a beaker. A completely submerged cylinder of specific gravity 0.9 adjusts itself so that its axis is vertical and two-thirds of its height projects above the A/W interface and one-third remains below. What is the specific gravity of A? Solve the problem two ways—first using Archimedes' law, and then using a momentum or force balance.




Fig. P1.10 U-tube with immiscible liquids.

10. Differential manometer—E. The U-tube shown in Fig. P1.10 has legs of unequal internal diameters d_1 and d_2 , which are partly filled with immiscible liquids of densities ρ_1 and ρ_2 , respectively, and are open to the atmosphere at the top.

¹⁰ D.L. Katz et al., Handbook of Natural Gas Engineering, McGraw-Hill, New York, 1959, p. 57, indicates a wide range of wettability by water, varying greatly with the particular rock formation.

If an *additional* small volume v_2 of the second liquid is added to the right-hand leg, derive an expression—in terms of ρ_1 , ρ_2 , v_2 , d_1 , and d_2 —for δ , the amount by which the level at B will fall. If ρ_1 is known, but ρ_2 is unknown, could the apparatus be used for determining the density of the second liquid?

Hints: The lengths h_A , h_B , and h_C have been included just to get started; they must not appear in the final result. After adding the second liquid, consider h_C to have increased by a length Δ —a quantity that must also eventually be eliminated.




Fig. P1.11 Bubble rising in a closed cylinder.

- 11. Ascending bubble—E. As shown in Fig. P1.11, a hollow vertical cylinder with rigid walls and of height H is closed at both ends, and is filled with an incompressible oil of density ρ . A gauge registers the pressure at the top of the cylinder. When a small bubble of volume v_0 initially adheres to point A at the bottom of the cylinder, the gauge registers a pressure p_0 . The gas in the bubble is ideal, and has a molecular weight of $M_{\rm w}$. The bubble is liberated by tapping on the cylinder and rises to point B at the top. The temperature T is constant throughout. Derive an expression in terms of any or all of the specified variables for the new pressure-gauge reading p_1 at the top of the cylinder.
- 12. Ship passing through locks—M. A ship of mass M travels uphill through a series of identical rectangular locks, each of equal superficial (bird's-eye view) area A and elevation change h. The steps involved in moving from one lock to the next (1 to 2, for example) are shown as A–B–C in Fig. P1.12. The lock at the top of the hill is supplied by a source of water. The initial depth in lock 1 is H, and the density of the water is ρ .
- (a) Derive an expression for the increase in mass of water in lock 1 for the sequence shown in terms of some or all of the variables M, H, h, A, ρ , and g.
- (b) If, after reaching the top of the hill, the ship descends through a similar series of locks to its original elevation, again derive an expression for the mass of water gained by a lock from the lock immediately above it.
- (c) Does the mass of water to be supplied depend on the mass of the ship if: (i) it travels only uphill, (ii) it travels uphill, then downhill? Explain your answer.




Fig. P1.12 Ship and locks.

13. Furnace stack—E. Air ($\rho_a = 0.08 \text{ lb}_m/\text{ft}^3$) flows through a furnace where it is burned with fuel to produce a hot gas ($\rho_g = 0.05 \text{ lb}_m/\text{ft}^3$) that flows up the stack, as in Fig. P1.13. The pressures in the gas and the immediately surrounding air at the top of the stack at point A are equal.




Fig. P1.13 Furnace stack.

What is the difference Δh (in.) in levels of the water in the manometer connected between the base B of the stack and the outside air at point C? Which side rises? Except for the pressure drop across the furnace (which you need not

worry about), treat the problem as one in hydrostatics. That is, ignore any frictional effects and kinetic energy changes in the stack. Also, neglect compressibility effects.




Fig. P1.14 Hydrometer in water and test liquid L.

14. Hydrometer—E. When a hydrometer floats in water, its cylindrical stem is submerged so that a certain point X on the stem is level with the free surface of the water, as shown in Fig. P1.14. When the hydrometer is placed in another liquid L of specific gravity s, the stem rises so that point X is now a height z above the free surface of L.

Derive an equation giving s in terms of z. If needed, the cross-sectional area of the stem is A, and when in water a total volume V (stem plus bulb) is submerged.




Fig. P1.15 Oil/mercury/water system.

15. Three-liquid manometer—E. In the hydrostatic case shown in Fig. P1.15, a=6 ft and c=4 ft. The specific gravities of oil, mercury, and water are $s_o=0.8$, $s_m=13.6$, and $s_w=1.0$. Pressure variations in the air are negligible. What is the difference b in inches between the mercury levels, and which leg of the manometer has the higher mercury level? Note: In this latter respect, the diagram may or may not be correct.

16. Pressure on Mt. Erebus—M. On page 223 of the biography Shackleton (by Roland Huntford, Atheneum, New York, 1986), the Antarctic explorer's colleague, Edward Marshall, is reported as having "... fixed the altitude [of Mt. Erebus] by hypsometer. This was simply a small cylinder in which distilled water was boiled and the temperature measured. It was then the most accurate known method of measuring altitude. The summit of Erebus turned out to be 13,500 feet above sea level."¹¹

Assuming a uniform (mean) air temperature of $-5\,^{\circ}\text{F}$ (the summer summit temperature is $-30\,^{\circ}\text{F}$), and a sea-level pressure of 13.9 psia, at what temperature did the water boil in the hypsometer? At temperatures $T=160,\ 170,\ 180,\ 190,\ 200,\ \text{and}\ 210\,^{\circ}\text{F}$, the respective vapor pressures of water are $p_v=4.741,\ 5.992,\ 7.510,\ 9.339,\ 11.526,\ \text{and}\ 14.123$ psia.

17. Oil and gas well pressures—M. A pressure gauge at the top of an oil well 18,000 ft deep registers 2,000 psig. The bottom 4,000-ft portion of the well is filled with oil (s=0.70). The remainder of the well is filled with natural gas ($T=60\,^{\circ}\mathrm{F}$, compressibility factor Z=0.80, and s=0.65, meaning that the molecular weight is 0.65 times that of air).

Calculate the pressure (psig) at (a) the oil/gas interface, and (b) the bottom of the well.

- 18. Thrust on a dam—E. Concerning the thrust on a rectangular dam, check that Eqn. (1.36) is still obtained if, instead of employing an upward coordinate z, use is made of a downward coordinate h (with h = 0 at the free surface).
- 19. Pressure variations in air—M. Refer to Example 1.5 concerning the pressure variations in a gas, and assume that you are dealing with air at $40\,^{\circ}$ F. Suppose further that you are using just the linear part of the expansion (up to the term in z) to calculate the absolute pressure at an elevation z above ground level. How large can z be, in miles, with the knowledge that the error amounts to no more than 1% of the exact value?
- **20.** Grand Coulee dam—E. The Grand Coulee dam, which first operated in 1941, is 550 ft high and 3,000 ft wide. What is the pressure at the base of the dam, and what is the total horizontal force F lb_f exerted on it by the water upstream?
- **21.** Force on V-shaped dam-M. A vertical dam has the shape of a V that is 3 m high and 2 m wide at the top, which is just level with the surface of the water upstream of the dam. Use two different methods to determine the total force (N) exerted by the water on the dam.
- **22.** Rotating mercury mirror—M. Physicist Ermanno Borra, of Laval University in Quebec, has made a 40-in. diameter telescopic mirror from a pool of

¹¹ A more recent value is thought to be 12,450 feet.

mercury that rotates at one revolution every six seconds.¹² (Air bearings eliminate vibration, and a thin layer of oil prevents surface ripples.)

By what value Δz would the surface at the center be depressed relative to the perimeter, and what is the focal length (m) of the mirror? The mirror cost Borra \$7,500. He estimated that a similar 30-meter mirror could be built for \$7.5 million. If the focal length were unchanged, what would be the new value of Δz for the larger mirror? *Hint*: the equation for a parabola of focal length f is $r^2 = 4fz$.

- **23.** Oil and water in rotating container—E. A cylindrical container partly filled with immiscible layers of water and oil is placed on a rotating turntable. Develop the necessary equations and prove that the shapes of the oil/air and water/oil interfaces are identical.
- **24.** Energy to place satellite in orbit—M. "NASA launched a \$195 million astronomy satellite at the weekend to probe the enigmatic workings of neutron stars, black holes, and the hearts of galaxies at the edge of the universe . . . The long-awaited mission began at 8:48 a.m. last Saturday when the satellite's Delta–2 rocket blasted off from the Cape Canaveral Air Station." ¹³

This "X-ray Timing Explorer satellite" was reported as having a mass of 6,700 lb_m and being placed 78 minutes after lift-off into a 360-mile-high circular orbit (measured above the earth's surface).

How much energy (J) went directly to the satellite to place it in orbit? What was the corresponding average power (kW)? The force of attraction between a mass m and the mass M_e of the earth is GmM_e/r^2 , where r is the distance of the mass from the center of the earth and G is the universal gravitational constant. The value of G is not needed in order to solve the problem, as long as you remember that the radius of the earth is 6.37×10^6 m, and that g = 9.81 m/s² at its surface.

25. Central-heating loop—M. Fig. P1.25 shows a piping "loop" that circulates hot water through the system ABCD in order to heat two floors of a house by means of baseboard fins attached to the horizontal runs of pipe (BC and DA). The horizontal and vertical portions of the pipes have lengths L and H, respectively.

The water, which has a mean density of $\overline{\rho}$ and a volume coefficient of expansion α , circulates by the action of natural convection due to a small heater, whose inlet and outlet water temperatures are T_1 and T_2 , respectively. The pressure drop due to friction per unit length of piping is cu^2/D , where c is a known constant, u is the mean water velocity, and D is the internal diameter of the pipe. You may assume that the vertical legs AB and CD are insulated, and that equal amounts of heat are dissipated on each floor.

Derive an expression that gives the volumetric circulation rate of water, Q, in terms of c, D, $\overline{\rho}$, α , g, L, H, T_1 , and T_2 .

¹² Scientific American, February 1994, pp. 76–81. There is also earlier mention of his work in Time, December 15, 1986.

Manchester Guardian Weekly, January 7, 1996.




Fig. P1.25 Central-heating loop.

26. Pressure at the center of the earth—M. Prove that the pressure at the center of the earth is given by $p_c = 3Mg_s/8\pi R^2$, in which g_s is the gravitational acceleration at the surface, M is the mass of the earth, and R is its radius. Hints: Consider a small mass m inside the earth, at a radius r from the center. The force of attraction mg_r (where g_r is the local gravitational acceleration) between m and the mass M_r enclosed within the radius r is GmM_r/r^2 , where G is the universal gravitational constant. Repeat for the mass at the surface, and hence show that $g_r/g_s = r/R$. Then invoke hydrostatics.

If the radius of the earth is $R = 6.37 \times 10^6$ m, and its mean density is approximately 5,500 kg/m³, estimate p_c in Pa and psi.




Fig. P1.27 Soap film on two rings.

27. Soap film on wire rings—M. As shown in Fig. P1.27, a soap film is stretched between two wire rings, each of diameter D and separated by a distance H. Prove that the radius R of the film at its narrowest point is:

$$R = \frac{1}{6} \left(2D + \sqrt{D^2 - 3H^2} \right).$$

You may assume that a section of the soap film is a circular arc, and that $D \ge \sqrt{3} H$. What might happen if D is less than $\sqrt{3} H$?

Clearly stating your assumptions, derive an expression for the radius, in terms of D and H. Is your expression exact or approximate? Explain.




Fig. P1.28 Person on a treadmill.

- 28. Treadmill stress test—M. What power P is needed to resist a force F at a steady velocity V? In a treadmill stress test (Fig. P1.28), you have to keep walking to keep up with a moving belt whose velocity V and angle of inclination θ are steadily increased. Initially, the belt is moving at 1.7 mph and has a grade (defined as $\tan \theta$) of 10%. The test is concluded after 13.3 min, at which stage the belt is moving at 5.0 mph and has a grade of 18%. If your mass is 163 lb_m: (a) how many HP are you exerting at the start of the test, (b) how many HP are you exerting at the end of the test, and (c) how many joules have you expended overall?
- **29.** Bubble rising in compressible liquid—D. A liquid of volume V and isothermal compressibility β has its pressure increased by an amount Δp . Explain why the corresponding increase ΔV in volume is given approximately by:

$$\Delta V = -\beta V \Delta p.$$

Repeat Problem P1.11, now allowing the oil—whose density and volume are initially ρ_0 and V_0 —to have a finite compressibility β . Prove that the ratio of the final bubble volume v_1 to its initial volume v_0 is:

$$\frac{v_1}{v_0} = 1 + \frac{\rho_0 g H}{p_0}.$$

If needed, assume that: (a) the bubble volume is much smaller than the oil volume, and (b) $\beta p_0 V_0 \gg v_1$. If $\rho_0 = 800 \text{ kg/m}^3$, $\beta = 5.5 \times 10^{-10} \text{ m}^2/\text{N}$, H = 1 m, $p_0 = 10^5 \text{ N/m}^2$ (initial absolute pressure at the top of the cylinder), $v_0 = 10^{-8} \text{ m}^3$, and $V_0 = 0.1 \text{ m}^3$, evaluate v_1/v_0 and check that assumption (b) above is reasonable.




Fig. P1.30 Well containing oil and methane.

- **30.** Pressures in oil and gas well—M. Fig. P1.30 shows a well that is 12,000 ft deep. The bottom H=2,000-ft portion is filled with an incompressible oil of specific gravity s=0.75, above which there is an h=10,000-ft layer of methane (CH₄; C = 12, H = 1) at 100 °F, which behaves as an ideal isothermal gas whose density is not constant. The gas and oil are static. The density of water is 62.3 lb_m/ft³.
- (a) If the pressure gauge at the top of the well registers $p_A = 1,000$ psig, compute the *absolute* pressure p_B (psia) at the oil/methane interface. Work in terms of symbols before substituting numbers.
- (b) Also compute $(p_C p_B)$, the additional pressure (psi) in going from the interface B to the bottom of the well C.




Fig. P1.31 Soap film between two disks.

31. Soap film between disks—E(C). A circular disk of weight W and radius a is hung from a similar disk by a soap film with surface tension σ , as shown in Fig. P1.31. The gauge pressure inside the film is P.

First, derive an expression for the angle θ in terms of a, P, W, and σ . Then obtain an equation that relates the radius of the neck r to a, P, W, and σ . Assume that: (a) the excess pressure inside a soap film with radii of curvature r_1 and r_2 is $2\sigma(1/r_1 + 1/r_2)$, and (b) the cross section of the film forms a circular arc.

32. Newspaper statements about the erg—E. In the New York Times for January 18, 1994, the following statement appeared: "An erg is the metric unit scientists use to measure energy. One erg is the amount of energy it takes to move a mass of one gram one centimeter in one second." (This statement related to the earthquake of the previous day, measuring 6.6 on the Richter scale, in the Northridge area of the San Fernando Valley, 20 miles north of downtown Los Angeles.)

Also in the same newspaper, there was a letter of rebuttal on January 30 that stated in part: "... This is not correct. The energy required to move a mass through a distance does not depend on how long it takes to accomplish the movement. Thus the definition should not include a unit of time."

A later letter from another reader, on February 10, made appropriate comments about the original article and the first letter. What do you think was said in the second letter?

- **33.** Centroid of triangle—E. A triangular plate held vertically in a liquid has one edge (of length B) coincident with the surface of the liquid; the altitude of the plate is H. Derive an expression for the depth of the centroid. What is the horizontal force exerted by the liquid, whose density is ρ , on one side of the plate?
- **34.** Blake-Kozeny equation—E. The Blake-Kozeny equation for the pressure drop $(p_1 p_2)$ in laminar flow of a fluid of viscosity μ through a packed bed of length L, particle diameter D_p and void fraction ε is (Section 4.4):

$$\frac{p_1 - p_2}{L} = 150 \left(\frac{\mu u_0}{D_p^2}\right) \left[\frac{(1 - \varepsilon)^2}{\varepsilon^3}\right].$$


- (a) Giving your reasons, suggest appropriate units for ε .
- (b) If $p_1 p_2 = 75 \text{ lb}_f/\text{in}^2$, $D_p = 0.1 \text{ in.}$, L = 6.0 ft, $\mu = 0.22 \text{ P}$, and $u_0 = 0.1 \text{ ft/s}$, compute the value of ε .
- **35.** Shear stresses for air and water—E. Consider the situation in Fig. 1.8, with h = 0.1 cm and V = 1.0 cm/s. The pressure is atmospheric throughout.
- (a) If the fluid is air at 20 °C, evaluate the shear stress τ_a (dynes/cm²). Does τ vary across the gap? Explain.
- (b) Evaluate τ_w if the fluid is water at 20 °C. What is the ratio τ_w/τ_a ?
- (c) If the temperature is raised to 80 °C, does τ_a increase or decrease? What about τ_w ?

36. 7	rue/false. Check true or false, as appropriate:14		
(a)	When a fluid is subjected to a steady shear stress, it will reach a state of equilibrium in which no further motion occurs.	Т	F 🗆
(b)	Pressure and shear stress are two examples of a force per unit area.	T 🗆	F \square
(c)	In fluid mechanics, the basic conservation laws are those of volume, energy, and momentum.	Т 🗆	F \square
(d)	Absolute pressures and temperatures must be employed when using the ideal gas law.	т 🗆	F 🗆
(e)	The density of an ideal gas depends only on its absolute temperature and its molecular weight.	Т 🗆	F 🗆
(f)	Closely, the density of water is $1,000 \text{ kg/m}^3$, and the gravitational acceleration is 9.81 m/s^2 .	Т 🗆	F 🗆
(g)	To convert pressure from gauge to absolute, add approximately 1.01 Pa.	Т 🗆	F 🗆
(h)	To convert from psia to psig, add 14.7, approximately.	$T \square$	F \square
(i)	The absolute atmospheric pressure in the classroom is roughly one bar.	т 🗆	F 🗆
(j)	If ρ is density in g/cm ³ and μ is viscosity in g/cm s, then the kinematic viscosity $\nu = \mu/\rho$ is in stokes.	Т 🗆	F \square
(k)	For a given liquid, surface tension and surface energy per unit area have identical numerical values and identical units.	Т	F 🗆
(1)	A force is equivalent to a rate of transfer of momentum.	Т 🗆	F 🗆
(m)	Work is equivalent to a rate of dissipation of power per unit time.	T 🗆	F \square
(n)	It is possible to have gauge pressures that are as low as -20.0 psig.	T 🗆	F \square
(o)	The density of air in the classroom is roughly 0.08 kg/m^3 .	Т 🗆	F 🗆
(p)	Pressure in a static fluid varies in the vertically upward direction z according to $dp/dz = -\rho g_c$.	Т 🗆	F 🗆

 $^{^{14}\,}$ Solutions to all the true/false assertions are given in Appendix B.

54 Chapter 1—Introduction to Fluid Mechanics

(q)	At any point, the rate of change of pressure with elevation is $dp/dz = -\rho g$, for both incompressible and compressible fluids.	Т	F 🗆
(r)	A vertical pipe full of water, 34 ft high and open at the top, will generate a pressure of about one atmosphere (gauge) at its base.	Т	F 🗆
(s)	The horizontal force on one side of a vertical circular disc of radius R immersed in a liquid of density ρ , with its center a distance R below the free surface, is $\pi R^3 \rho g$.	Т	F 🗆
(t)	For a vertical rectangle or dam of width W and depth D , with its top edge submerged in a liquid of density ρ , as in Fig. 1.15, the total horizontal thrust of the liquid can also be expressed as $\int_0^D \rho ghW dh$, where h is the coordinate measured $downwards$ from the free surface.	Т	F \square
(u)	The horizontal pressure force on a rectangular dam with its top edge in the free surface is F_x . If the dam were made twice as deep, but still with the same width, the total force would be $2F_x$.	Т	F \square
(v)	A solid object completely immersed in oil will experience the same upward buoyant force as when it is immersed in water.	Т	F [
(w)	Archimedes' law will not be true if the object immersed is hollow (such as an empty box with a tight lid, for example).	Т	F 🗆
(x)	The rate of pressure change due to centrifugal action is given by $\partial p/\partial r = \rho r^2 \omega$, in which ω is the angular velocity of rotation.	Т	F 🗆
(y)	To convert radians per second into rpm, divide by 120π .	Т	F 🗆
(z)	The shape of the free surface of a liquid in a rotating container is a hyperbola.	т 🗆	F 🗆
(A)	The hydrostatic force exerted on one face of a square plate of side L that is held vertically in a liquid with one edge in the free surface is F . If the plate is lowered vertically by a distance L , the force on one face will be $3F$.	Т	F \square



Α thrust, 443 flow in, using COMSOL, 448 Absolute pressure, 8 Bernoulli, Daniel, biographi-Aggregatively fluidized beds, cal sketch, 68 560, 566 Bernoulli's equation, 67, 355, fluid flow in, 569 384, 533 particle flow in, 468 compressible flow, 161 pressure distribution in, generalized, 64 567 Bézier curves in COMSOL, Analogies, between momentum and heat transfer, Bingham plastic fluids, 594, 600 Angular momentum, 81 in pipe flow 600 Angular velocity, 4, 39, 258, Blake-Kozeny equation, 207 355 Blasius equation, 129, 428, Annular die, flow through, 493, 495, 511 322 Blasius solution for boun-Annular flow, 543, 552 dary layer flow, 425 A.P.I., degrees, 11 Blow molding, 313 Archimedes, biographical Blunt-nosed object, flow sketch, 36 past, 358, 383 Archimedes' law, 37 Bob-and-cup viscometer, 627 Archimedes number, 200 Body force, 56, 79 Axially symmetric irrota-Body-force potential, 321 tional flow, 378 Boltzmann distribution, 649 Boltzmann's constant, 131 Boolean operations in В COMSOL, 722 Boundary, 9, 55 Balances, energy, 9, 55, 61 Boundary conditions, 293 mass, 9, 55, 57 Boundary layers, 414 momentum, 9, 55, 78 application to turbulent Basis or shape function, in jets, 513 finite-element methods, dimensional analysis of, 681 430

Bearing, journal, 443

simplification of equations of motion for, 422 solution using COMSOL, 435 turbulent, 428 Boundary settings in COM-SOL, 712, 724, 727 Bourdon-tube pressure gauge, 89 Brinkman equation with COMSOL, 729 Brownian motion, 129 Bubble caps, dynamics of, in distillation columns, 216 Bubble flow in vertical pipes, 543, 545 Bubbles, in fluidized beds, 560 formation at an orifice, 563 rise velocity of, 562, 572 Bubbles, rise velocity of, 531, 545 Bubbles, terminal velocity, 532 Buckingham Pi theorem, 227 Buffer region, 490 Buoyancy, 36 Burke-Plummer equation, 207

\mathbf{C}

Cake, in a filter, 210 Calendering, 313, 401, 450 pressure distribution in, 455

laminar, 415

Capillary pressure, in porous medium, 393 Capillary tube, for surface tension, 19 Capillary viscometer, 623 Caprock, 395 Carreau model, 599, 607 Cascade process in turbulence, 474 Centrifugal filter, 214 Centrifugal pump, 164, 189 Characteristic time, 596 Charge number, 644 "Choking" of the throat, 163 Churchill, S.W., Reynolds stress correlation, 496 interpolation between two asymptotic limits, 498 Coating a moving substrate, 461 Coating or spreading, 313 Coaxial cylinder rheometer, 627 Coefficient of contraction, 71 Coefficient of discharge, 73 Coefficient of thermal expansion, 12 Coions, 649 Colebrook and White equation, 136, 494 Commercial pipe, sizes, 138 Complex piping systems, 163 Composite object, COM-SOL, 712, 723 Compressibility factor, 12 Compressibility, isothermal, Compressible flow of gases, in a nozzle, 159 in a pipeline, 156 with COMSOL, 729 Compressive stress, 6 Computational fluid dynamics (CFD), 473, 671 applications in chemical engineering, 672 COMSOL, Inc., 703, 705 COMSOL Multiphysics, examples involving, boundary-layer flow, 435

die flow, non-Newtonian, electroosmosis, 653, 657 jet flow and mixing, 505 lake flow, 373 lubricated bearing, 448 momentum diffusion, 307 multiphysics, 653, 657 orifice plate, 501 parallel-plate flow, 435 porous-medium flow, 705 screw extruder, 318 turbulent flow, 501, 505 COMSOL Multiphysics, capabilities of, 703 axes and grid settings, 710 Bézier curves, 720 Boolean operations, 722 boundary settings, 712, 724 composite object, 712, 723 documentation, 705 draw mode, 719 draw toolbar, 711 equations solvable by, 704 graphical user interface, 708 how to run, 705 interior boundaries menus and toolbars, 709 mesh, 715, 716 model library model navigator, 706 multiphysics, 653, 657 physics modes, 703 plot parameters, 718 postprocessing, 717 problems solvable by, 725 solving a problem, 717, 724 subdomain settings, 714, 724 surface plot, 716 Cone-and-plate viscometer, 328, 626 Connate water, 392 Conservation laws, 9, 55 Constitutive equations, Bingham model, 594,600

Carreau model, 599 generalized Newtonian fluids, 598 general viscoelastic fluids, 615 Maxwell model, 615 Newtonian fluids, 296, 595 power-law model, 599 White-Metzner model, 619 Contact force, 56, 79 Continuity equation, 59, 72, 267, 268 time-averaged, 477 Control surface, 55 for momentum transfer, 81 Convection of momentum, 81 Convective derivative, 266, 619 Converging/diverging nozzle, 159 Conversion factors, table of, inside front cover, 25 Coriolis mass-flow meter, 95 Couette flow, 294, 312, 316, 328 in lubrication, 447 Counterions, 649 Critical pressure for compressible gas flow, 158, 163 Cross product, 251 Curl of a vector, 259 expressions for, 266 Curvature, 458, 735 Curved surface, change in pressure across, 18, 458 Cyclone separation, 219 Cylinder, flow past, computed by FlowLab, 195, 696 drag coefficient, 699 Cylindrical coordinates, 263 mass balance in, 268 momentum balances in, 322 solution of problems in, 322

 \mathbf{D}

d'Arcy's law, 207, 388, 392, 706 Dam, force on, 32 Deborah number, 596 Debye-Huckel limit, 650 Debye length, 650 Deformation of a fluid element, 275, 357 Del (nabla) operator, in rectangular coordinates, 265 Density, 10 °A.P.I.. 11 Derivative, definition of, 27, 257 Derivatives, 731 Derived quantities, 225 Diameter, hydraulic mean, 151 Die swell, 614 Dies, flow through, 313, 322 non-Newtonian, 606 Differential equations, solution of, separation of variables, spreadsheets, 466, 734 Differential mass balance, 267 Differential momentum balance, 271 Diffuser, in a nozzle, 159 Diffusion coefficient, 15 Diffusion in microchannels, 642 Diffusion of momentum, 307 Dilatant fluids, 593, 599, 603 Dimensional analysis, 224 Dimensional analysis of boundary layer flow, 430 Dimensionless groups, for drag force, 196 filtration, 224 flow through packed beds, 206 laminar sublayer, 230 pipe flow, 132, 134 pumps, 192 Dimensionless numbers,

table of, 228 Dimensionless shear stress, 132, 491 Dimensions, 226 mass, length, and time, 10 Directional derivative, 252 Discharge coefficient, 73 Discretization, in numerical methods, 674 Dissipation, see frictional dissipation Dissipation, turbulent, 499 transport equation for, 500 Distillation column, dynamics of bubble caps, 216 Dittus-Boelter equation, 511 Divergence of a vector, 254 expressions for, 265 Dot product, 250 Double-dot product, 597 Doublet, 384 Drag coefficient, 196 Drag coefficient on a flat plate, 415, 419, 428, 429, 432 Drag force, 194 Draw mode in COMSOL, 719 Draw toolbar in COMSOL, Drawing or spinning, 312 Droplet, excess pressure inside, 18 Ducts, flow in noncircular, 150 Dyadic product, 619, 740

\mathbf{E}

Dynamical similarity, 229

Eddies, 131, 474, 480 formation of, 475 Eddy diffusivity, 483 Eddy kinematic viscosity, 132, 482, 483, 484 correlation for, 486 determination of, 485 in turbulent jets, 518 Eddy thermal diffusivity, 483 Eddy transport, 481 Elastic modulus, 621 Elastic recoil, 617 Electrical double layer, 647, 648, 649 Electric charge, 644 flux of, 645 Electric field, 644 Electric potential, 646, 649, 650 Electrokinetic flow, 639, 664 Electrokinetic forces, 664 Electroosmosis, 647, 651 measurement of, 659 Electroosmosis in a microchannel (COMSOL), 653, 657 Electroosmotic flow around a particle, 653 Electroosmotic mobility, 647 Electrophoresis, 645, 664 Electrophoretic mobility, 645 Electrostatic precipitator, 202 Electroviscosity, 661 Energy balance, 55, 62, 598, pipe flow, 126, 128 Energy, conservation of, 9.55 English units, 22 Entrance region between flat plates, 440 Eötvös number, in slug flow, 549 Equations of motion, 268, 281, 294, 322, 327 solutions of, 293 Equipment, visual encyclopedia of, 185 Equipotentials, 366 in microfluidics, 656, 658 Equivalent length of fittings, 154 Ergun equation, 206 Euler equation, 355, 397 Euler's method, 733 Eulerian viewpoint, 267 Excel spreadsheets, 143, 145, 146, 150, 167, 454 Extrusion of polymer, 312

 \mathbf{F}

Falling-sphere viscometer, 202 Fanning friction factor, 132, 133, 135, 136, 137 Faraday's constant, 649 FEMLAB—see under its new name, COMSOL Multiphysics Fick's law, 644 Film flow, 456 Film, in lubrication, 443 Filtrate, 210 Filtration, 210 centrifugal, 213 plate-and-frame, 210 rotary-vacuum, 212 Finite-difference methods, 674 Finite-element methods, 680 Finite-volume methods, 676 Fittings, equivalent length, 154 Five-spot pattern, 391 Flooding, 555 Flow energy, 62 Flow, around sphere, 194 in noncircular ducts, 150 in open channels, 151 past a flat plate, 415, 428 through a porous medium, 207 through packed beds, 204 FlowLab, examples involving, flow in pipe entrance, 687 flow past a cylinder, 696 sudden expansion, 690 two-dimensional mixing, 692 FlowLab, CFD software, 682 geometry panel, 684 graphical user interface, mesh and solve panels, 685 operation toolpad buttons, 683 physics, boundary condition, and materials

panels, 684 reports and postprocessing panels, 686 Flow rates, 9 Flow rate, measurement of, by Coriolis meter, 95 by orifice plate, 71 by rotameter, 89 Flow regimes in two-phase flow. horizontal pipes, 541 vertical pipes, 543 Fluent, Inc., 682 Fluid, definition of, 9 Fluid mechanics, laws of, 9 Fluidization, 215, 559 aggregative, 560, 566 particulate, 559 Fluidized bed, 559 reaction in, 572 Flux, 8, 254 Force, 22 as a rate of momentum transfer, 79 on arbitrary surfaces, 33 on dam, 32 power for displacement of, 64 units of, 21 Forced vortex, 39, 356 Form drag, 194 Fourier's law, 256, 260 Fox, T.R.C., xvii, 456 footnote Free surface, 28, 33 of rotating fluid, 39 Free vortex, 40, 220, 356 Friction factor, 124 analogy with the Stanton number, 510 as a dimensionless group, 132, 210 in terms of Re, 135, 491 Friction-factor plot, 135 Friction velocity, 489 Frictional dissipation, 63, 598 noncircular ducts, 151 open channels, 152

packed beds, 207 pipe flow, 126, 134 Froude number, in slug flow, 549 Fundamental dimensions, 225

\mathbf{G}

Galerkin's method, 681 Gas constant, values of, 12 Gas law, 11 Gas-lift pump, 550 Gas, pressure variations in, 31 Gas, underground storage of, 395 Gases, 5 flow of compressible, 156, 159 viscosity of, 131 Gauge pressure, 8 Gate valve, 154 gc, conversion factor, 22 General linear viscoelastic fluids, 615, 618 Generalized Maxwell model, 618 Geometrical shapes, 731 Geometrical similarity, 229 Globe valve, 154 Gradient of a scalar, 252 expressions for, 265 Graphical interface, for COMSOL, 708

\mathbf{H}

Hagen-Poiseuille law, 125
Harrison, D., bubble formation in fluidized beds, 565
Head, of fluid, 68
Head/discharge curve for centrifugal pump, 192
Heat transfer, analogy with momentum transfer, 509

Hookean solid, 616
Hoop stress in pipe wall, 139
Hydraulic mean diameter,
151
Hydraulically smooth pipe,
136
Hydrostatics, 26
multiple fluids, 30

Ι

Impeller, of pump, 91, 190

Incipient fluidization, 215, 559 Infinite-shear viscosity, 599 Injection molding, 312 Integrals, 731 Intensity of turbulence, 477 Internal energy, 61 Invariants of the strain-rate tensor, 597 Inviscid fluid, motion of, 321 Irrigation ditch, 152 Irrotational flow, 260, 356 axially symmetric, 378 in cylindrical coordinates, 363 in rectangular coordinates, 361 line source, 370 past a blunt-nosed object, 358, 383 past a cylinder, 367 past a sphere, 386 point source, 382 stagnation flow, 369, 383 uniform flow in, 366, 380 Irrotationality condition, for axially symmetric flow, 379 for cylindrical flow, 364 for rectangular flow, 361 Isentropic expansion, 160 Isothermal compressibility, 12 Isothermal flow of gas in pipe, 156

J

Jet mixing, COMSOL computation of, 505 FlowLab computation of, 692 Journal bearing, 443

\mathbf{K}

Karamanev, D.G., method for terminal velocities, 200 Kármán vortex street, 475, 697 k/ε method for turbulent flows, 499 with COMSOL, 726 with FlowLab, 690 Kinematic viscosity, 15, 512 Kinetic energy, 61, 67 for pipe flow, 127 Kinetic energy, turbulent, 499 transport equation for, 500 Kolmorogov limit, 474, 476 Kronecker delta, 251

\mathbf{L}

Lagrangian viewpoint, 266

Lake flow, with COMSOL, Lamb, Horace, feelings about turbulence, 473 Laminar flow, friction in, frictional dissipation, 126 friction factor for, 134 in a pipe, 122, 123 Laminar flow, unstable, 475, 700 Laminar sublayer, 155, 490 dimensional analysis of, 229 thickness of, 155, 493 Laminar velocity profile, 124, 155 Laplace, Pierre Simon, Mar-

quis de, biographical sketch, 362 Laplace's equation, 262 in irrotational flow, 362, 364, 379 for axially symmetric flow, 379 with COMSOL, 727 Laplacian operator, 262 expressions for, 266 Laws of fluid mechanics, 9 Leibnitz's rule, 618 footnote, 736 Leung, L.S., bubble formation in fluidized beds, 565 Linear viscoelasticity, 615 Line source, 370 Liquids, 5 Lockhart/Martinelli correlation, 539, 552 Logarithmic velocity profile, 487, 490 Lorentz force, 646 Loss angle, 621 Loss modulus, 621 Lubrication approximation, Lubrication flow, with COM-SOL, 448

\mathbf{M}

Macintosh computer for COMSOL, 706 Magnetic settling, 662 Manometer, 93 Mass, 21 conservation of, 9, 55 Mass balance, 55, 57 steady state, 57 Mass flow rate, 9 Mass velocity, 157 Material types, 591 MATLAB, xvi, 613, 703, 704, 706 Maxwell, James Clerk, biographical sketch, 616 Maxwell model, 615

Memory function, 618 Mesh refinement in COMSOL, 715, 725 Microfluidics, 639 chips for, 640 Microscale fluid mechanics, 640 Mist flow, 475 Mixing length, correlation for, 485 determination of, 484 Mixing-length theory, 481 for turbulent jets, 515 Model navigator, in COMSOL, 706 Moment of inertia, 90 Momentum, 78 angular, 90 balance, 55, 78 conservation of, 55, 79 diffusion of, 307 Momentum balance, for bubble formation at an orifice, 564 in film flow, 405 shell, 301 time-averaged, 478 Momentum transfer, by convection, 9, 81 by force, 79 in laminar flow, 129 in turbulent flow, 131 Momentum transfer, analogy with heat transfer, 509 Moody friction factor, 132

\mathbf{N}

Natural gas, underground storage of, 395 Navier, Claude-Louis-Marie-Henri, biographical sketch, 281 Navier-Stokes equations, 278, 281 in microfluidics, 646 with COMSOL, 725 Needle valve, 154 Newton, Sir Isaac, bio-

graphical sketch, 131 law of viscosity, 124, 130 second law of motion, 21, 27 Newtonian fluid, 4, 14, 124, 130, 275, 276, 279, 591, 598 Nicklin, D.J., correlation for two-phase slug flow, 548 Nikuradse, pipe friction experiments, 136 Nonlinear simultaneous equations, 149, 166 Non-Newtonian flow in a die, with COMSOL, 606 viscosity profiles, 611 Non-Newtonian flows using COMSOL, 728 Non-Newtonian fluid, 4, 592 Normal stresses, 271, 276, viscoelastic, 613 Normal-stress difference, 613 No-slip boundary condition, 273 Nozzle, gas flow in, 159 Numerical methods for solving fluid mechanics problems, 673

\mathbf{o}

Oldroyd derivative, 620

One-seventh power law, 493, 495 Open-channel flow, 151 Order-of-magnitude analysis, for boundary-layer flow, 423 for turbulent jets, 513 Ordinary differential equations, solution of, 733 Orifice, flow through, compressible, 159 incompressible, 70 Orifice-plate "meter," 71 Orifice plate, COMSOL solution, 88, 501 pressure recovery, 504 Oscillatory shear, with COMSOL, 309 Ostwald-de-Waele model, 599

Р

Packed beds, 204 Packed-bed reactor, pressure drop in, 208 Packed column, flooding of, 556 Paint films, leveling of, 463 Parabolic velocity profile, 124, 155 Parallel-plate rheometer, 627 Particle motion in microfluidic channels, 661 Particles, settling of, 199, 201, 222 Particulate phase ("emulsion"), in fluidization, 560 PC for COMSOL, 706 Péclet number, 643 Permeability, 208, 387, 391, 396 Permittivity, 646, 654 Physical properties, 10 Piezoelectric and piezoresistive effects in pressure transducer, 93 Piezometer, 93 Piezometric tube, 69, 93 Pipe fittings, pressure drop, 154 Pipe flow, Bingham plastic, power-law fluid, 600 Pipe flow, pressure drop in, 123, 133, 139 Pipe roughness, 136 Pipeline, for gas, 156 Pipes, flow through, 120 Piping systems, 149, 163 Pitot tube, 74 Pitot-static tube, 74 Plate-and-frame filter, 210 Plot parameters in COMSOL, 718 Point source, 381 Poiseuille flow, 294, 312, 316 in lubrication, 447 Poisson's equation, in lubrication, 445

Poisson's equation, solution of, by COMSOL, 373, 727 by finite-element methods, by finite-difference methods, 674 microfluidics, 646 Polymath, 150, 164 Polymer processing, 312, 450 Pores, flow through, 205 Porosity, 391, 396 Porous medium, flow through, 207, 566 single-phase, 364, 388, 390 two-phase, 390 with COMSOL, 728 Potential, for porousmedium flow, 392 Potential energy, 61 Potential flow, 261, 361 Power. for flowing stream, 64 for force displacement, 64 for pump, 64 for rotating shaft, 64 Power-law fluids, 599, 600 Power-law velocity profile, 495, 603 Prandtl hypothesis, 486 Prandtl, Ludwig, biographical sketch, 434 Prandtl mixing length, 483 Prandtl-Taylor analogy, 510 Pressure, 6 absolute, 8 gauge, 8 Pressure as a function of height, 26 Pressure change caused by rotation, 39 Pressure distribution, in calendering, 454 in fluidized beds, 567 Pressure drop, across pipe fittings, 154 in pipe flow, 123, 133, 139 Pressure drop in two-phase flow horizontal pipes, 536

vertical pipes, 549, 552 Pressure forces on submerged objects, 36 Pressure head, 68 Pressure measurement, 92 Pressure transducer, 93 Primary recovery of oil, 390 Projected area, 196 Pseudoplastic fluids, 593, 599, 603 Pump impeller, 91, 190 Pumps, centrifugal, 164, 189 positive displacement, 188, 189 Pumps in series and parallel, 193

\mathbf{R}

Rabinowitsch equation, 624 Radius of curvature, 735 Rate laws, 57 Rate-of-deformation tensor, Rate-of-strain tensor, 279, 596 invariants of, 597 Reaction in fluidized bed, Reciprocating pumps, 188 Recirculation in sudden expansion, in jet mixing, with FlowLab, 694 using FlowLab, 691 Rectangular coordinates, 249 mass balance in, 268 momentum balances in, 272, 281 problems in, 294 Rectangular duct, flow through, 150, 294 Reference quantities, 430 Relaxation modulus, 618 Relaxation time, 616 Residual oil, 392 Reynolds analogy, 509

Reynolds experiment, 121

Reynolds number, 73, 122, 228 for boundary-layer flow, 415, 428 for drag force, 196 in microfluidics, 641 in pipe flow, 134, 135, 137, 149 Reynolds, Osborne, biographical sketch, 121 Reynolds stresses, 479 correlation for, 496 Rheometers, 625 Rheopectic fluids, 594 Richardson-Zaki correlation, 222, 560 Rod-climbing effect, 614 Rotameter, 89 Rotary pumps, 189 Rotary-vacuum filter, 212 Rotating fluid, 39 Rotational flow, 356 Rotational rheometers, 625 Roughness, pipe, 136 Rough pipe, flow in, 136, 494

\mathbf{S}

Saturation, in porous medium, 391 Scalars, 249 Schedule number for pipe, 137 Screw extruder, 313 with COMSOL, 318 Secondary recovery of oil, 390 Sedimentation, 222 Separation of variables, 733 Settling of particles, 199, 201, 222 Shacham equation, for turbulent friction factor, 137, 150 Shear stress, 3, 6, 14, 271, 274 dimensionless groups for pipe flow, 225 distribution, 124, 300, 605

in pipe flow, 80, 123 models for, 129 Shear-thickening fluids, 593, 604 Shear-thinning fluids, 593, 599, 604 Shell momentum balance, 301 Shock, in gas flow, 159, 163 SI units, 21, 23 Sign convention for stresses, 271 Similar velocity profiles, 417 Simple shear, 592, 597, 615 Simpson's rule, 733 Simultaneous nonlinear equations, 149, 166 Slug flow in vertical pipes, 543, 547 Slurry, 210 Smooth pipe, flow in, 490 Solenoidal flow, 256 Solids, 591, 616 Solution procedure, for viscous-flow problems, 293 Sound, speed of, 159, 163 Source in a uniform stream, 382 Specific gravity, 13 Sphere, drag force on, 194, 434 Sphere, flow past, 194, 386, 434 Spherical coordinates, 263 mass balance in, 268 momentum balances in, 283 solution of problems in, 327 Spherical-cap bubbles, 533 Sphericity, particle, 197, 198 Spinning of fibers, 325 Spray drier, 201 Spreadsheets, 143, 145, 146, 150, 167, 454, 734 Spreadsheet solution of differential equations, 734 Spring/dashpot model, 617

Stagnation flow, 369, 383 Stagnation point, 369, 383, 533 Static head, 68 Steady in the mean, 87, 421 Steady-state energy balance, Steady-state mass balance, 59 Steady-state problems, 57 Stokes, Sir George Gabriel, biographical sketch, 198 Stokes' law, 198 Storage modulus, 621 Strain rate, 592, 595, 598 for non-Newtonian flow in a die, 613 Strain-rate tensor, 279, 596 Stream function, 362, 364, 378 for boundary layers, 426 for turbulent jets, 516, 518 physical interpretation of, 364, 378 Streaming potential, 659 Streamlines, 57, 355, 366 in microfluidics, 656, 658 Stream tube, 62 Strength, of a doublet, 384 of a line source, 370 of a point source, 381 Stress and strain, for viscoelastic fluid, 622 Stress, compressive, 6 tensile, 5 Stress, sign convention for, 271 Stress relaxation, 617 Stress tensor, 274, 279, 595 Strong conservation form, 673, 676 Strouhal number, 699 Subdomain settings in COMSOL, 714, 724 Substantial derivative, 266 Sudden expansion, after orifice plate, 86 in a pipe, 88 solved by FlowLab, 690 Superficial velocity, 205

Supersonic velocity, 159, 162
Surface energy, 17
Surface plot in COMSOL,
716
Surface roughnesses, 136
Surface tension, 16
in thin-film flow, 456
methods for measuring, 19
Surface waves, 396
Surroundings, 9, 55
System, 9, 55

\mathbf{T}

Tangential stresses, 6, 272, 274Tank draining, 70 evacuation, 58 filling, 76 Taylor dispersion, 642 Taylor, Geoffrey Ingram, biographical sketch, 534 Taylor's expansion, 31, 733 Tensile stress, 5 Tensors, 274, 279, 595, 740 "divergence" of, 741 "Laplacian" of, 741 Terminal velocities of spheres, 199 Karamanev method, 200 Tertiary recovery of oil, 390 Thermal diffusivity, 512 Thermal expansion, coefficient of, 12 Thin films, 456 Thixotropic fluids, 594 Thrust bearing, 443 Time-averaged continuity equation, 477 momentum balance, 478 Time-averaging, 476 Torque, 91, 191 power for rotation of, 64 Total head, 69 Transducer, for measuring pressure, 93 Transient problems, 57 Transient viscous diffusion of momentum

(COMSOL), 307 Transition flow, 121 Turbulence, 122, 124, 473 computation by the k/ε method, 499 intensity of, 477 k/ε method for, 499 mixing-length theory, 481 momentum transport in, 131, 480, 509 orifice-plate flow, 501 solved by COMSOL, 726 solved by FlowLab, 690, 692 velocity profiles, 155, 487, 490, 492 Turbulent boundary layers, 428 Turbulent core, 155, 229, 490, 492 Turbulent energy, 474, 499 dissipation rate ε , 499 fluctuations, 475, 476, 479 Turbulent jets, 513 axisymmetric, 519 plane, 514 Turbulent properties computed by COMSOL, dissipation, 503, 508 kinematic viscosity, 503, 507 kinetic energy, 503, 508 Turbulent transport, summary of, 483 Two-phase flow in porous media, 390 Two-phase flow in pipes, horizontal pipes, 536 vertical pipes, 543

\mathbf{U}

Underground flow of water, 364, 388 Underground storage of natural gas, 395 Unit vectors, 250 Universal velocity profile, 488 Unstable laminar flow, 475, 700 Unsteady-state problems, 57 Usagi, R., interpolation between two asymptotic limits, 498

\mathbf{v}

Vanes, of centrifugal pump,

Variable-viscosity momen-

Valve, for pipeline, 154

190

tum balance, 284 Vector components, 250 Vector differentiation, 251 Vectors, 249 addition and subtraction, dyadic product, 740 multiplication, 250 Velocity, 8 Velocity head, 68 Velocity, no-slip boundary condition, 293 Velocity of sound, 159, 162 Velocity potential, 260, 361, 364, 379 Velocity profiles, boundarylayer flow, 417, 418, 426, 428 calendering, 453, 463 concentric cylinders, 4 development in entrance region, 440 lubrication, 444 parallel plates, 14 pipe flow, 124, 155, 487, 490 turbulent flow, 487, 490, 492 turbulent jets, 517, 520 viscous flow, 124, 297, 305, 316, 324, 331 Vena contracta, 71 Viscoelastic fluids, 613, 618 constitutive equations, 613 phase relations, 622, 623 Viscometers, 625

Viscosity, 3, 13 eddy kinematic, 131, 483 kinematic, 15, 512 of gases, 131 Viscous dissipation function, 598 Viscous drag, 194 Viscous-flow problems, 292 Viscous modulus, 621 Visual encyclopedia of chemical engineering equipment, 185 Void fraction, 205 in two-phase flow, 536, 544, 549 Volumetric flow rate, 9 Volute chamber, 190 Von Kármán hypothesis, 487 Vortex, forced, 39, 356 free, 40, 356 Vortex formation during jet mixing, 506 Vortex lines, 355 Vortex shedding past a cylinder, 698 Vorticity, 260, 355, 358 for non-Newtonian flow in a die, 612 source term for, 373

\mathbf{W}

Waterflooding, 391
Wave motion in deep water, 396
paths followed by particles, 399
Weight, 21
Weir, in distillation column, 217
Weissenberg effect, 614
Weissenberg, lectures of, 592
Weissenberg rheogoniometer, 328, 626
Wetted perimeter, 150
Weymouth equation, 157
White-Metzner model, 619
Work, 56, 61

 \mathbf{Y}

Yield stress, 594, 600

 ${f Z}$

Zajic, S.C., Reynolds stress correlation, 496
Zero-shear boundary condition, 294
Zero-shear viscosity, 599
Zeta potential, 647, 649, 651
Zoom extents, 375, 501, 506